



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	(844738)	1	Instrument panel		24V, Obsolete part
2	844723	1	• Instrument plate		
3	842563	1	• Tachometer		
4	(837758)	1	• Thermometer		Obsolete part
5	(837756)	1	• Instrument		Obsolete part
6	(837730)	1	• Voltmeter		Obsolete part
7	824963	1	• Starter switch		
8	(831606)	2	• • Key		For cable area 6,5-10,5mm <sup>2</sup> ., Obsolete part
			Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
9	(831536)	1	• Nut		Obsolete part
10	(827769)	1	• Collar		Obsolete part
11	843684	2	• Button		
12	837533	2	• Rubber cap		
13	842918	1	• Rheostat		
14	843002	1	• Nut		
15	842921	1	• Knob		
16	808175	5	• Lamp socket		
17	819350	5	• Sleeve		
18	182059	5	• Bulb		
19	827766	5	• Lens		
20	(837859)	2	• Anchorage		Obsolete part
21		1	•		
22		1	•		
23		X	• • cable and cable terminals	14577	
24	948210	X	• • • Cable tie		(827353)
25	944540	4	• • • Screw		
26	837722	1	• • • Resistor		
27	837878	1	• • • Relay		
28	955126	1	• • • Cross recessed screw		
29	(192557)	1	• • • Spring nut		Obsolete part