



5396

**HEAT EXCHANGER AND THERMOSTAT WITH INSTALLATION
COMPONENTS: TMD120B**

02B

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	844102	1	Heat exchanger		
2	822629	1	· Heat exchanger housi		
3	823661	4	· Zinc electrode		(823660) REPL BY 823661
4		4	· · ZINC ELECTRODE		
5		4	· · · PLUG		
6	1544390	3	· Thermostat		81-94%Z9
7	416033	3	· Sealing ring	IK	
8	822628	1	· Thermostat retainer		
9	942342	4	· Screw		
10	941670	4	· Washer		
11	822618	1	· Heat exchanger eleme		
12	925278	4	· O-ring		
13	955977	1	· Rubber ring		
14	822621	1	· End cover		
15	844040	1	· Cover		
16	955598	1	· Screw		
17	941912	1	· Spring washer		
18	955536	8	· Screw		
19	942336	8	· Spring washer		
20	836169	4	· Gasket	IK	
21	803311	1	· Lifting eye		
22	949918	3	Drain cock		(82745)
23	959979	6	Screw		
24	942551	6	Washer		
25	822574	1	End cover		
26	822554	1	Gasket	IK	
27	836746	1	Sealing ring	IK	
28	955535	2	Screw		
29	942338	4	Screw		
30	942336	6	Spring washer		
31	822631	1	Cover		
32	822632	1	Gasket	IK	
33	955536	6	Screw		
34	955538	4	Screw		
35	942336	10	Spring washer		
36	823580	1	Connection flange		
37	842137	1	Gasket	IK	
38	950158	4	Screw		
39	192618	X	Hose		L = 1000 MM
40	823036	1	Bracket		
41	820730	1	Bracket		
42	955541	3	Screw		
43	955535	1	Screw		
44	940162	4	Screw		
45	940156	1	Screw		
46	955539	2	Screw		
47	942336	12	Spring washer		
48	955543	1	Screw		
49	820232	1	Sign		
50	950210	3	Screw		
51	180761		Plug		REPLACED BY 1EA 1544389.
52	11996		Gasket	IK	REPLACED BY 1EA 1544389.
53	952077		Plug		REPLACED BY 1EA 1544389.
54	190998	1	Plug		
55	423352	1	Gasket	IK	02B-0775
56	837044	1	Temperature sensor		SEE GROUP 3
57		1	· THERMOSWITCH ALARM		SEE GROUP 3
58	836841	1	Exhaust pipe		02B-1175
59	822575	6	Sealing ring		02B-1175
60	321973	1	Filler cap		
61	843584	2	Sealing ring		
62	956569	8	Screw		
63	941907	8	Spring washer		

