



4518

4519

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	836986	1		
2		1	• TURBINE HOUSING	
3	837076	1	• Rotor unit	
4		1	• • BEARING HOUSING	
5	422659	1	• • Turbine rotor	
6		4	• • PISTON RING	IK
7	467026	2	• • Thrust ring	
8	422660	1	• • Spacer sleeve	
9		2	• • BEARING	IK
10	422661	1	• • Ring retainer	
11	417727	4	• • Lock ring	IK
12		1	• • SLEEVE	IK
13		1	• • THRUST BEARING	IK
14	422662	1	• • Splash plate	IK
15	420466	1	• • Cover	
16		1	• • O-RING	IK
17	420467	1	• • Lock ring	
18	837079	1	• • Compressor wheel	
19	1518784	1	• • Nut	(422669)
20	417378	1	• • Gasket	IK
21	417381	1	• • Gasket	IK
22		1	• • TURBINE BACKPLATE	
23	422360	1	• • Lock ring	IK
24		1	• HOUSING	
25	422667	1	• Clamp	
26	1695417	1		(420473)
27	417382	1	• Gasket	IK
28	961896	7	• Plug	
29	957188	7	• Gasket	
30	955524	10	• Screw	
31	941907	10	• Spring washer	
32	955984	10	• Sealing ring	
35	837080	1	Repair kit	