



4518

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	842427	1	Turbo	
	3802009	1	Turbocharger, exch	Exchange unit
2		1	• TURBINE HOUSING	
3	843420	1	• Rotor unit	
4		1	• • BEARING HOUSING	
5	467554	1	• • Turbine rotor	
6		2	• • PISTON RING	IK
7	467026	2	• • Thrust ring	
8	422660	1	• • Spacer sleeve	
9		2	• • BEARING	IK
10	467556	1	• • Ring retainer	
11	417727	4	• • Lock ring	IK
12		1	• • SLEEVE	IK
13		1	• • THRUST BEARING	IK
14	422662	1	• • Splash plate	IK
15	467557	1	• • Cover	
16		1	• • O-RING	IK
17	420467	1	• • Lock ring	
18	467558	1	• • Compressor wheel	
19	1518784	1	• • Nut	(422669)
20	417378	1	• • Gasket	IK
21	417381	1	• • Gasket	IK
22		1	• • TURBINE BACKPLATE	
23	422360	1	• • Lock ring	IK
24		1	• HOUSING	
27	417382	1	• Gasket	IK
28	961896	8	• Plug	
29	957188	8	• Gasket	
30	955524	10	• Screw	
31	941907	10	• Spring washer	
32	955984	10	• Sealing ring	
33	843421	4	• Washer	
34	940100	8	• Screw	
35	843422	8	• Washer	
35	843424	1	Repair kit	