



4680

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	1542155	1	Injector	
	3803239	1	Injector, exch	Exchange unit
2		1	• NOZZLE HOLDER BODY	
3	844294	1	• Gasket	
4	844295	1	• O-ring	
5	844296	1	• Fitting	
6	844297	1	• Thrust ring	
7	844298	1	• Lock ring	
8	244797	1	• Adjusting washer, SHIM	(844299)
	846960	1	• Adjusting washer, SHIM	TH = 1,000 MM ALT (844300)
	846945	1	• Adjusting washer, SHIM	TH = 1,025 MM ALT (844301)
	846961	1	• Adjusting washer, SHIM	TH = 1,050 MM ALT (844302)
	844303	1	• Adjusting washer	TH = 1,075 MM ALT
	244804	1	• Adjusting washer, SHIM	TH = 1,100 MM ALT (6212418)
	846947	1	• Adjusting washer, SHIM	TH = 1,125 MM ALT (844342)
	846963	1	• Adjusting washer	TH = 1,150 MM ALT (844343)
	244799	1	• Adjusting washer, SHIM	TH = 1,175 MM ALT (844304)
	6212417	1	• Adjusting washer, SHIM	TH = 1,200 MM ALT (844305)
	244805	1	• Adjusting washer, SHIM	TH = 1,225 MM ALT (846948)
	244807	1	• Adjusting washer, SHIM	TH = 1,250 MM ALT (846964)
	844308	1	• Adjusting washer	TH = 1,280 MM ALT
	244789	1	• Adjusting washer, SHIM	TH = 1,300 MM ALT (846965)
	858908	1	• Adjusting washer, SHIM	TH = 1,320 MM ALT (846950)
	846966	1	• Adjusting washer, SHIM	TH = 1,340 MM ALT (844311)
	244800	1	• Adjusting washer, SHIM	TH = 1,375 MM ALT (844312)
	6212393	1	• Adjusting washer, SHIM	TH = 1,400 MM ALT (844313)
	244790	1	• Adjusting washer, SHIM	TH = 1,425 MM ALT (846952)
	244807	1	• Adjusting washer	TH = 1,440 MM ALT (844315)
	844316	1	• Adjusting washer	TH = 1,475 MM ALT
	244791	1	• Adjusting washer, SHIM	TH = 1,500 MM ALT (846968)
	846954	1	• Adjusting washer, SHIM	TH = 1,525 MM ALT (844318)
	858906	1	• Adjusting washer, SHIM	TH = 1,550 MM ALT (846969)
	244793	1	• Adjusting washer, SHIM	TH = 1,580 MM ALT (844320)
	846970	1	• Adjusting washer	TH = 1,600 MM ALT
	244806	1	• Adjusting washer, SHIM	TH = 1,625 MM ALT (846956)
	244803	1	• Adjusting washer	TH = 1,640 MM ALT (844323)
	858905	1	• Adjusting washer	TH = 1,675 MM ALT (844324)
	244794	1	• Adjusting washer	TH = 1,700 MM ALT (844325)
				TH = 1,725 MM ALT

REF	PART NO.	QTY	DESCRIPTION	NOTES
8	846957	1	· Adjusting washer	TH = 1,750 MM ALT
	846975	1	· Adjusting washer, SHIM	(844327)
	844328	1	· Adjusting washer	TH = 1,775 MM ALT
	6212420	1	· Adjusting washer	TH = 1,800 MM ALT
				(844329)
				TH = 1,825 MM ALT
	846958	1	· Adjusting washer, SHIM	(844330)
				TH = 1,850 MM ALT
	244813	1	· Adjusting washer, SHIM	(846977)
				TH = 1,880 MM ALT
	844332	1	· Adjusting washer	TH = 1,900 MM ALT
	244795	1	· Adjusting washer, SHIM	(846978)
				TH = 1,925 MM ALT
	244795	1	· Adjusting washer, SHIM	(846959)
				TH = 1,920 MM ALT
	846980	1	· Adjusting washer, SHIM	(844335)
				TH = 1,975 MM ALT
9	844336	1	· Spring	
10	844337	1	· Push rod	
11	844338	1	· Washer	
12	844339	2	· Locating pin	
13	1542303	1	· Nozzle	
14	844340	1	· Nut	