



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
2	838060	1	Starter motor		
	3803077	1	Starter motor, exch		Exchange unit
				030-1100	
3	840272	1	Cover		
4	955343	2	Screw		
6	963108	2	Nut		
7	955782	1	Nut		
8	941907	1	Spring washer		
10		1	ALTERNATOR AND INSTALLATION COMPONENTS	030-0800	
12	955945	1	Washer		
13	190663	1	Screw		
14	957181	1	Gasket	IK	
15	1502028	1	Tachometer sensor		SPEC 867663
16	957181	1	Gasket	IK	SPEC 867663
17	840074	1	Temperature sensor		SPEC 867663. SPEC 867389, 867419.
	833927	1	Thermo monitor		(840077)
19	833909	1	Instrument panel		SPEC 867663. SPEC 867389, 867419.
				030-1250	
	833929	1	Alarm panel		
				030-1300	
20	840078	1	Cable trunk		
	840046	1	Cable trunk		SPEC 867663. SPEC 867389, 867419.
21	833618	X	Extension cable\verl		L = 2000 MM
	833619	X	Extension cable\verl		L = 5000 MM
23		X	CABLES AND TERMINALS	030-1350	
25	870730	1	Actuator solenoid		STARTER CUT-OUT RELAY FOR UNLIMITED BATTERY CAPACITY.
26	239964	1	Regulator		STARTER CUT-OUT RELAY FOR UNLIMITED BATTERY CAPACITY.
27	942198	1	Clamp		
28	948210	X	Strip clamp		(827353)
29	824823	1	Fuse box		
30	840013	1	Instrument panel, EXTRA		
31	839128	1	· Plug		
32	944540	4	· Screw		
33	834397	1	Voltmeter		
34	834374	1	· Voltmeter		
35	19923	1	· Bulb		
36	808175	1	· Bulb socket		

