




D3-110i-A, D3-130i-A, D3-160i-A, D3-130A-A, D3-160A-A, D3-110i-B, D3-130i-B, D3-160i-B, D3-190i-B, D3-130A-B, D3-160A-B, D3-190A-B



D3-110i-A, D3-130i-A, D3-160i-A, D3-130A-A, D3-160A-A, D3-110i-B, D3-130i-B, D3-160i-B, D3-190i-B, D3-130A-B, D3-160A-B, D3-190A-B

REF	PART NO.	QTY	DESCRIPTION
1	3812605	1	Cover
2		1	· Cover
3	3812607	1	· Cup
4	3819953	1	· Cover plate
5	969456	4	· 6 point socket screw
6	888512	4	· Bracket
7	8642162	4	· Rubber cushion
8	969476	4	· Screw
9	888382	1	Decal
10	888383	1	Decal
11	3584298	1	Decal
12	3812572	1	Decal