


D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D



23

WARNING

⚠ Avoid moving parts of machinery to prevent injury or death due to moving parts or proper contact.

⚠ Do not play on the motor platform when engine is running.

⚠ Propellers can spin without warning and injure anyone nearby.

⚠ Do not enter the water while engines are running. Boat can move suddenly.

⚠ Read service manual for the 2012 edition. 11 888

24

WARNING

When DPS is in Use Boats Underway



⚠ Maintain proper LOOKOUT

⚠ STAY OUT of water spinning propellers.

⚠ HOLD ON to prevent fall a boat can move suddenly

⚠ READ the owner's manual

Failure to observe warnings may result in SEVERE INJURY or DEATH.



24857

D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	21300833	1	Antenna kit	
2	(21300831)	1	• Antenna	Obsolete part
3	21231832	1	• • Sensor	
4	21395738	1	• • Antenna base	
5	478344	2	• • Spacer sleeve	
6	994153	2	• • Hex. socket screw	
7	941670	6	• • Washer	
8	994138	6	• • Hex. socket screw	
9	21328699	2	• • Decal	
10	21300823	1	• • Antenna base	
11	21300829	1	• • Tensioning ring	
12	21330777	1	• • Hollow screw	
13	994153	3	• Hex. socket screw	
14	941670	3	• Washer	
15	993419	3	• Washer	
16	946330	3	• Hexagon nut	
17	21303890	1	• Cable grommet	
18	961314	1	• Cross recessed screw	
19	874960	1	• Insulator	
20	874961	1	• Coding key	
21	8397660	1	• Plug	
22	21231837	1	• Converter	
23	21318999	1	• Decal	
24	21325536	1	• Label	