

DESCRIPTION	SEE SEC.	NOTES
Flywheel Housing and Primary Shaft	7574	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-260A-A, D4-260A-B, D4-260A-C, D4-300A-A, D4-300A-C, DPH-A, DPH-B, DPR-A, DPR-B
Exhaust Pipe and Cooling Water Pipe DPH/DPR Drive Unit	35258	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-225A-E, D4-260A-E, D4-300A-E, DPH-A, DPH-B, DPR-A, DPR-B
Actuator	8864	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-225A-E, D4-260A-E, D4-300A-E, DPH-A, DPH-B, DPR-A, DPR-B
Jack Shaft Kit	21872	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-225A-E, D4-260A-E, D4-300A-E, DPH-A, DPH-B, DPR-A, DPR-B
Jack Shaft Kit	37093	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-225A-E, D4-260A-E, D4-300A-E, DPH-A, DPH-B, DPR-A, DPR-B
Jack Shaft, Connecting Components	21940	D4-180I-B, D4-180I-C, D4-180I-D, D4-180I-E, D4-210I-A, D4-210I-B, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300I-A, D4-300I-C, D4-300I-D, D4-225A-E, D4-225I-E, D4-260A-E, D4-260I-E, D4-300A-E, D4-300I-E, DPH-A, DPH-B, DPR-A, DPR-B
Jack Shaft, Connecting Components	37092	D4-210A-A, D4-210A-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-225A-E, D4-260A-E, D4-300A-E, DPH-A, DPH-B, DPR-A, DPR-B
Connecting Kit for Borg Warner SAE4 and SAE7	8144	D4-180I-B, D4-180I-C, D4-180I-D, D4-180I-E, D4-210I-B, D4-225I-B, D4-225I-C, D4-225I-D, D4-260I-B, D4-260I-C, D4-260I-D, D4-300I-A, D4-300I-C, D4-300I-D, D4-225I-E, D4-260I-E, D4-300I-E
Connecting Kit Reverse Gear HS45AE	35797	D4-180I-C, D4-180I-D, D4-180I-E, D4-225I-B, D4-225I-C, D4-225I-D, D4-225I-E
Connecting Kit Reverse Gear HS45AE	35061	D4-225I-B, D4-225I-C, D4-225I-D, D4-225I-E
Connecting Kit Reverse Gear HS63AE	35082	D4-225I-B, D4-225I-C, D4-260I-A, D4-260I-B, D4-260I-C
Connecting Kit Reverse Gear HS63AE	35761	D4-300I-A, D4-300I-C, D4-300I-D, D4-300I-E
Connecting Kit Reverse Gear HS63IVE	35080	D4-180I-B, D4-180I-C, D4-225I-B, D4-225I-C, D4-260I-A, D4-260I-B, D4-260I-C
Connecting Kit Reverse Gear HS63IVE	35273	D4-300I-A, D4-300I-C, D4-300I-D, D4-300I-E
Connecting Kit Reverse Gear HS80AE	35050	D4-300I-A, D4-300I-C, D4-300I-D, D4-300I-E
Connecting Kit Reverse Gear HS80AE. SN2004017199-	35049	D4-300I-A
Steering Motor EVC-C	21953	D4-260D-B, D4-260D-C, D4-300D-A, D4-300D-C
Steering Motor EVC-C3	35923	D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D
Steering Motor EVC-D	36254	D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D
Mounting Kit, Clamp Ring	36715	D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D
Connecting Shaft and Housing, Diesel, 335mm	36720	D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D
Connecting Shaft and Housing, Diesel, Length >335mm	36721	D4-260D-B, D4-260D-C, D4-260D-D, D4-300D-A, D4-300D-C, D4-260D-E, D4-300D-E, D4-300D-D