

DESCRIPTION	SEE SEC.	NOTES
Short Block, exchange	9862	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D
Short Block, exchange	21914	D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Cylinder Head, exchange	35109	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Cylinder Head, exchange	35102	D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Cylinder Block and Flywheel Housing	6300	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Camshaft And Camshaft Chain	6599	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Crank Mechanism	6360	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D
Crank Mechanism	21980	D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Balance Shaft Housing	6378	D4-180I-B, D4-180I-C, D4-180I-D, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225A-C, D4-225A-D, D4-225I-B, D4-225I-C, D4-225I-D, D4-260A-A, D4-260A-B, D4-260A-C, D4-260A-D, D4-260D-B, D4-260D-C, D4-260D-D, D4-260I-A, D4-260I-B, D4-260I-C, D4-260I-D, D4-300A-A, D4-300A-C, D4-300A-D, D4-300D-A, D4-300D-C, D4-300D-D, D4-300I-A, D4-300I-C, D4-300I-D
Engine Mounting, Earlier Production	6541	D4-180I-B, D4-210I-A, D4-210I-B, D4-225I-B, D4-260D-B, D4-260I-A, D4-260I-B
Engine Suspension, Later Production	21977	D4-180I-B, D4-210I-A, D4-210I-B, D4-225I-B, D4-260D-B, D4-260I-A, D4-260I-B, D4-300D-A, D4-300I-A
Engine Mounting, Earlier Production	7850	D4-210A-A, D4-210A-B, D4-225A-B, D4-260A-A, D4-260A-B, D4-260D-B
Engine Suspension, Later Production	21978	D4-210A-A, D4-210A-B, D4-225A-B, D4-260A-A, D4-260A-B, D4-260D-B, D4-300A-A, D4-300D-A
Engine Suspension	35147	D4-180I-C, D4-180I-D, D4-225I-C, D4-225I-D, D4-260D-C, D4-260I-C, D4-260I-D, D4-300D-C, D4-300D-D, D4-300I-C, D4-300I-D
Engine Suspension	35146	D4-225A-C, D4-225A-D, D4-260A-C, D4-260A-D, D4-260D-C, D4-260D-D, D4-300A-C, D4-300A-D, D4-300D-C, D4-300D-D
Protecting Cover	6581	D4-180I-B, D4-210A-A, D4-210A-B, D4-210I-A, D4-210I-B, D4-225A-B, D4-225I-B, D4-260A-A, D4-260A-B, D4-260D-B, D4-260I-A, D4-260I-B, D4-300A-A, D4-300D-A, D4-300I-A
Protecting Cover	35101	D4-180I-C, D4-180I-D, D4-225A-C, D4-225A-D, D4-225I-C, D4-225I-D, D4-260A-C, D4-260A-D, D4-260D-C, D4-260D-D, D4-260I-C, D4-260I-D, D4-300A-C, D4-300A-D, D4-300D-C, D4-300D-D, D4-300I-C, D4-300I-D