



16110

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	847580	1	Heat exchanger, standard		REPLACED BY 864916
				706	
	864916	1	Heat exchanger, classifiable		As a spare part a classified heat exchanger is obtained.
				706	
2	479979	1	Plug		
3A	332262	1	Nipple		Replaced by plug 3825335.
3B	861551	1	Plug		Replaced by plug 3825335.
3C	3825335	1	Plug		LATE TYPE
4	863367	1	Cover		
5	949805	2	O-ring		
6	944926	4	Flange screw		
6A	946173	4	Flange screw		
7	941907	8	Spring washer		
8	949805	2	O-ring		
9	848576	1	Connection pipe		Throttle housing-after cooling.
10	955296	4	Screw		
11	941907	4	Spring washer		
12	864723	2	Sealing ring		
13		1	Starter elementBy-pass valve With install. comps.	645	
14	847819	1	Connection pipe		Turbo-throttle housing.
15	864722	1	Sealing ring		
16	3825376	1	Connection pipe		(847770). After cooler-inlet manifold.
16A	479979	2	· Plug		
17	955296	4	Screw		
18	941907	4	Spring washer		
19	960632	1	Plug		
20	947624	1	Gasket		
21	469508	1	Sealing ring		
22	848101	1	Bracket		
23	946173	4	Flange screw		
24	864970	1	Coolant pipe		After cooler-heat exchanger.
25	466739	1	Sealing ring		
26	466739	1	Sealing ring		
27	864973	1	Coolant pipe		SEE GROUP 44
28	864918	1	Retainer		
29	849606	1	Bracket		
30	864479	1	Bracket		
31	945414	1	Screw		L=14mm
32	946036	2	Lock nut		
33	945444	2	Flange screw		
		1	Pressure sensor		SEE GROUP 30