
.

÷.,



25



REF	PART NO.		DESCRIPTION	NOTES
1	3802062	1		(848276)
2		1		
3		1	<ul> <li>Compressor housing</li> </ul>	
4		1	<ul> <li>Bearing housing</li> </ul>	
5	(838563)	1		Obsolete part
6	(838562)	2		Included in repair kit 3830711., Obsolete part
7		1	<ul> <li>Piston ring</li> </ul>	Included in repair kit 3830711.
7A		2	<ul> <li>Piston ring</li> </ul>	Included in repair kit 3830711.
8	(845042)	4	<ul> <li>Lock ring</li> </ul>	Obsolete part, Included in repair kit 3830711.
9	(858710)	1	<ul> <li>Thrust bearing</li> </ul>	Obsolete part, Included in repair kit 3830711.
10	(845047)	1	<ul> <li>Oil deflector</li> </ul>	Obsolete part, Included in repair kit 3830711.
11	849587	1	• Rotor	Replaced by 1 ea rotor 3827354, 1 ea compressor wheel 3827363 and 1 ea overhaul kit 3827366.
11A	849588	1	• • Rotor	
12	(849589)	1	Compressor wheel	Obsolete part
13	(844000)	1		Obsolete part
14	(845050)	1	• • Sleeve	Obsolete part
15	(858674)	1	• • Bushing	Obsolete part
15A	(858675)	1	• • Seal	Obsolete part
16	(848711)	1		Obsolete part, Included in repair kit 3830711.
17	(=)	1	Thrust plate	
18	845829	4	Screw	Included in repair kit 3830711.
19	847643	1	• O-ring	Included in repair kit 3830711.
20	955270	8		Included in repair kit 3830711., (858661)
21	(838426)	1	O-ring	Obsolete part, Included in repair kit 3830711.
22	(847646)	4		Obsolete part, Included in repair kit 3830711.
23	955269	6		Included in repair kit 3830711.
24	(838578)	3		Obsolete part, Included in repair kit 3830711.
25	849590	1		See group 99
20	3827366	1		

