



| REF | PART NO. | QTY | DESCRIPTION    | NOTES  |
|-----|----------|-----|----------------|--|
| 1   | 8192050  | 1   | Coolant pump   |  |
| 2   |          | 1   | • Housing      |  |
| 3   | 1675808  | 1   | • Impeller     | Included in repair kit 3830711.  |
| 4   | 468249   | 1   | • Shaft        | Included in repair kit 3830711.  |
| 5   | 421549   | 1   | • Shaft        | Included in repair kit 3830711.  |
| 6   | 471497   | 1   | • O-ring       | Included in repair kit 3830711.  |
| 7   | 1674237  | 1   | • Cover        | Included in repair kit 3830711.  |
| 8   | 471495   | 1   | • Lock spring  | Included in repair kit 3830711.  |
| 9   | 1676432  | 1   | • Sealing ring | Included in repair kit 3830711.  |
| 10  | 958811   | 1   | • Sealing ring | Included in repair kit 3830711.  |
| 11  | 471499   | 1   | • Ball bearing | Included in repair kit 3830711.  |
| 12  | 471493   | 1   | • Lock ring    | Included in repair kit 3830711.  |
| 13  | 471501   | 1   | • Gear         |  |
| 14  | 11992    | 1   | • Gasket       |  |
| 15  | 947107   | 1   | • Flange screw |  |
|     | 849971   | 1   | Drain plug     | Plug 849971 should be used at marine engines. Screw 947107 should be dismantled. |
| 16  | 276942   | 1   | Water pump kit | See group 99   |