


TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74L-A, TAMD74P-A, TAMD74C-B, TAMD74L-B, TAMD74P-B, TAMD75P-A



TAMD74A-A, TAMD74A-B, TAMD74C-A, TAMD74L-A, TAMD74P-A, TAMD74C-B, TAMD74L-B, TAMD74P-B, TAMD75P-A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	3826153	1	Circulation pump		REPL BY 3836405
				5274	
	3836405	1	Circulation pump		
	3803915	1	Circ. pump, exch		Exchange unit
				5274	
2	975691	1	O-ring		
3	3829027	1	Plate		(3826294)
4	866533	2	Allen head screw		
5	1161231	X	Sealant		
5A	925255	1	O-ring		
6	965216	1	Screw		
7	945444	4	Flange screw		
8	966871	1	Tap		
9	866186	1	Pulley		
10	946440	4	Flange screw		
11	3830674	1	Hose		Heat exchanger-water pump.
12	961672	2	Clamp		
13	3826313	1	Hose		
14	961670	2	Hose clamp		
15	866213	1	Connector housing		
16	471816	1	Sealing ring		
17	941907	2	Spring washer		
18	945444	2	Flange screw		
19	876628	1	Thermostat housing		
20	1544710	1	Sealing ring		
21	477059	1	O-ring		
22	975673	1	O-ring		
23	3826304	1	Water pipe		
24	945444	2	Flange screw		
25	961672	2	Clamp		
26	3826314	1	Hose	4891	Thermostat housing-heat exchanger.
27	955782	10	Nut		
27A	941908	3	Spring washer		
27B	965189	3	Flange screw		
28	1661993	1	Thermostat		75°C
29	477905	1	Cover		
30	471788	1	Sealing ring		
31	941907	4	Spring washer		
32	946470	4	Flange screw		
33	949658	1	O-ring		
34	3825377	1	Flange		With hole for sender with M16 thread.
	3830530	1	Flange		With hole for sender with M18 thread.
35	945444	2	Flange screw		
36	11998	1	Gasket		
37		1	Temperature sensor		SEE GROUP 30
38	947624	1	Gasket		
39		1	Temperature sensor		SEE GROUP 30
40	469982	1	Sealing ring		
41	848165	1	Tube		
42	848163	1	Gasket		
43	946544	2	Flange screw		
44	954385	2	Elbow nipple		
45	954364	2	Fitting		
46	944717	2	Sleeve		
47	954356	2	Cap nut		
48	945460	X	Plastic pipe		L=1110mm. Thermostat housing-heat exchanger.
49	3827273	1	Drive belt		
50		1	Screw	4468	