



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843979	1	Injection pump		
				02C-0450	
2	823781	1	Tube		CYL. NO. 1
3	823782	1	Tube		CYL. NO. 2
4	823783	1	Tube		CYL. NO. 3
5	823784	1	Tube		CYL. NO. 4
6	823785	1	Tube		CYL. NO. 5
7	823786	1	Tube		CYL. NO. 6
8	414346	8	Clamp		
9	414347	8	Rubber spacer		
10	414344	2	Clamp		
11	414345	2	Rubber spacer		
12	955247	10	Screw		
13	414736	1	Nut plate		
14	414735	2	Nut plate		
15	837097	6	Injector		
	3803249	6	Injector, exch		Exchange unit
				02C-0700	
16	941928	12	Stud		
17	417110	12	Nut		
18	822564	1	Leak-off pipe		
19	836747	1	Tube		
20	74034	1	Hollow screw		
21	74033	6	Hollow screw		
22	957171	12	Gasket		
23	243405	1	Fuel filter		
				02C-0750	
24	845319	1	Bracket		(836365)
25	940134	2	Screw		
26	941909	2	Spring washer		
27	940115	2	Screw		
28	942336	2	Spring washer		
29	846457	1	Reservoir		
29A	960630	1	Plug		
29B	947621	1	Gasket		
30	846460	1	Sealing ring		
30A	846458	1	Sealing ring		
31	846459	1	Cover		
32	959223	1	Screw		L = 30 MM
	959227	1	Screw		L = 50 MM
33	941907	2	Spring washer		
34	846461	2	Wing screw		
35	947620	2	Gasket		
35A	951665	2	Retaining ring		
36	35096	2	Overflow valve		
37	18671	7	Gasket	IK	
38	836748	1	Tube		
39	837610	1	Fuel pipe		
40	180211	1	Hollow screw		
41	16496	1	Hollow screw		
42	957171	3	Gasket	IK	
43	836750	1	Tube		
44	836749	1	Tube		
45	26013	2	Hollow screw		
46	957181	4	Gasket	IK	
47	25167	3	Hollow screw		
48	957178	7	Gasket	IK	
49	422246	1	Pipe		
50	954394	1	Hollow screw		
51	11998	1	Gasket	IK	
52	423393	1	Pressure oil line		
53	48634	1	Hollow screw		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
54	957173	2	Gasket	IK	
55	837709	1	Hollow screw		SEE GROUP 2B
56	11994	1	Gasket	IK	
57	18666	1	Gasket	IK	
58	466398	1	Pressure equalizer		
59	18671	1	Gasket	IK	
60	821134	1	Lever		SEE GROUP 2D
61	955270	1	Screw		SEE GROUP 2D
62	941906	1	Spring washer		SEE GROUP 2D
63	468558	1	Bracket		
64	955566	4	Screw		
65	940280	4	Spring washer		
66	940156	4	Screw		
67	190509	4	Washer		
68	837607	1	Fuel pipe		
69	25167	1	Hollow screw		
70	18671	2	Gasket	IK	
71	845450	2	Fuel hose		
72	956969	4	Ferrule		
73	956983	4	Nut		
74	821625	1	Anchorage		
75	821036	1	Clamp		
76	952625	2	Clamp		
77	950046	3	Screw		
78	941906	3	Spring washer		
79	955825	3	Nut		
80	821076	1	Clamp		
81	941492	1	Clamp		
82	822546	1	Bracket		SEE GROUP 2B
83			DRIVE DEVICE, FUEL INJECTION PUMP	02C-0350	
84	846127	1	Delivery pipe		CYL.NO.1. INCLUDED IN FUEL INJECTOR.
85	846126	1	Delivery pipe		CYL.NO.2. INCLUDED IN FUEL INJECTOR.
86	846125	1	Delivery pipe		CYL.NO.3. INCLUDED IN FUEL INJECTOR.
87	846124	1	Delivery pipe		CYL.NO.4. INCLUDED IN FUEL INJECTOR.
88	846123	1	Delivery pipe		CYL.NO.5. INCLUDED IN FUEL INJECTOR.
89	846122	1	Delivery pipe		CYL.NO.6. INCLUDED IN FUEL INJECTOR.
90	846119	1	Spacer		
91	959800	1	Screw		SEE GROUP 2B
92	942336	1	Spring washer		
93	843028	1	Spacer sleeve		
94	955288	1	Screw		
95	941906	1	Spring washer		
96	955781	1	Nut		
97	846121	1	Leak-off pipe		
98	846183	6	Hollow screw		
99	845953	12	Gasket		
100	844130	1	Tube		SEE GROUP 3
101	956969	1	Ferrule		
102	956983	1	Nut		
103	404279	4	Clamp		
104	956095	2	Screw		
105	941906	2	Spring washer		
106	955781	2	Nut		
107	423161	2	Guide sleeve		
108	417588	1	Guide sleeve		
109	25168	1	Banjo nipple		
110	957178	2	Gasket		
111	25167	1	Hollow screw		
112	846120	2	Clamp		