



5410

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	843978	1	Injection pump		
2	844970	1	· Governor		
				02C-0600	
3	243083	1	· Feed pump		
				02C-0650	
4		1	· PUMP HOUSING		
5	239982	6	· Tappet		
6	240779	6	· · Bolt		
7	240780	6	· · Bushing		
8	240781	6	· · Roller		
9	238379	6	· · Plate		
10	239986	6	· Spring disc		
11	244065	6	· Spring		(239985)
12	239984	6	· Spring disc		
13	240782	6	· Control sleeve		
14	239991	6	· Cover		
15	241677	6	· Washer		
16	239990	6	· Lock ring		
17	240003	6	· Spacer ring		
18	240002	6	· O-ring		
19	240424	X	· Gasket		TH = 0,15 MM
	240004	X	· Gasket		TH = 0,40 MM
	240005	X	· Gasket		TH = 0,50 MM
	240006	X	· Gasket		TH = 0,60 MM
	240007	X	· Gasket		TH = 0,70 MM
	240008	X	· Gasket		TH = 0,80 MM
20	243741	6	· Bushing		
21	18836	6	· Gasket		
22	240422	12	· O-ring		
23	243266	6	· Pump element		
24	240423	6	· Delivery valve		
25	239993	6	· Gasket		
26	240969	6	· Spring		
27	240001	6	· Gasket		
28	243742	6	· Delivery valve retai		
29	243743	12	· Washer		
30	240010	12	· Screw		
31	941908	12	· Spring washer		
32	955783	12	· Nut		
33	240011	1	· Cover		
34	956209	2	· Screw		
35	18891	2	· Lock washer		
36	240907	1	· Control rod		
37	240014	2	· Guide sleeve		
38	244008	1	· Lock pin		(131015)
39	240015	1	· Bushing		
40	956090	2	· Screw		
41	941906	2	· Spring washer		
42	241647	1	· Setting indicator		
43	240971	6	· Plug		
44	240972	X	· Washer		TH = 0,2 MM
	240973	X	· Washer		TH = 0,5 MM
45	240429	6	· Plug		
46	243263	1	· Plug		
47	240017	1	· Gasket		
48	243267	1	· Camshaft		
49	240426	1	· Bearing		
50	240427	2	· Screw		
51	941906	2	· Spring washer		
52	240023	1	· Roller bearing		
53	240022	1	· Sealing ring		

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
54	243299	1	· O-ring		
55	240024	X	· Adjusting washer		TH = 0,10 MM
	240025	X	· Adjusting washer		TH = 0,12 MM
	240026	X	· Adjusting washer		TH = 0,14 MM
	240027	X	· Adjusting washer		TH = 0,16 MM
	240028	X	· Adjusting washer		TH = 0,18 MM
	240029	X	· Adjusting washer		TH = 0,30 MM
	240030	X	· Adjusting washer		TH = 0,50 MM
56	240021	1	· Cover		
57	956094	4	· Screw		
58	941906	4	· Spring washer		
59	955806	1	· Nut		
60	941913	1	· Spring washer		
61	35168	1	· Key		
62	240023	1	· Roller bearing		
63	240032	1	· Ring		
64	240033	X	· Adjusting washer		TH = 1,2 MM
	240034	X	· Adjusting washer		TH = 1,5 MM
	240035	X	· Adjusting washer		TH = 1,8 MM
	240036	X	· Adjusting washer		TH = 2,0 MM
65	240947	1	· Cover		
66	240948	1	· Gasket		
67	956205	12	· Screw		
68	239896	1	· Gasket		
69	130673	3	· Stud		
70	955781	3	· Nut		
71	941906	3	· Spring washer		
72	240121	1	· Plug		