

Upd: 21 NOV 2005

22



Oil Pump, Components: 470343

		ΟΤΥ	DESCRIPTION	NOTES
	Г NO. ′0343	QTY	DESCRIPTION Oil pump	NUTES
1 47	00-0	- 1		
2		1	Housing	
3 47	0347	2	• • Bushing	Included in overhaul kit.
)1146	2	· · Guide sleeve	
5		1	· Bracket	(470349)
6 47	0347		Bushing Pin	Included in overhaul kit.
7 19 8	1171	1 1	Stub	Included in overhaul kit.
9		1	Shaftwith gear	Included in overhaul kit.
10		1	• Gear	Included in overhaul kit.
11 47	0356	1	• Gear	EARLY TYPE
	8232	1	Drive gear	LATE TYPE
12 95	5531	2	Screw	
13 94	1907	2	Spring washer	Included in overhaul kit.
14 42	2047	1	Gear	
15 42	2314	1	Bushing Bogring allows	
16 42 17 94	2313	1 3	Bearing sleeve Spring washer	
	0186	3	Spring washer Screw	
10 94	0115	<u> </u>	· Key	EARLY TYPE
20 47	0357	1	• Washer	EARLY TYPE
21 27	6156	1	Overhaul kit	SEE GROUP 99



Upd: 21 NOV 2005