


4.3GLPWTC, 4.3GLPWTR, 4.3GSPWTC, 4.3GSPWTR, 4.3GIPWTC, 4.3GIPWTR, 4.3GIJWTR, 4.3GSJWTR



24444

4.3GLPWTC, 4.3GLPWTR, 4.3GSPWTC, 4.3GSPWTR, 4.3GIPWTC, 4.3GIPWTR, 4.3GIJWTR, 4.3GSJWTR

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852602	2	Hose clamp, hose to thermostat housing	
2	3853780	5	Hose clamp, hose them hsg to exhaust manifold	
3	3853391	1	Flange screw, alignment bracket & thermostat hsg	
4	(3852649)	1	Bracket, alignment bracket	Obsolete part
5	3853401	1	Flange screw, thermostat hsg to engine	
6	3850360	1	Housing, thermostat hsg	
7	3857843	2	Hose, thermostat hsg to manifold	Cut to length; port
8	3858237	1	Hose, pump to thermostat hsg	
	944386	1	Rubber hose, PJX to thermostat hsg	1.425mm; as required
9	3858235	1	Hose, cooler to pump	GL, GS
	3858236	1	Hose, cooler to pump	Gi
10	3853786	2	Hose clamp, hose, water pump inlet	
11	3852477	2	Gasket, water pump to block	Part of engine gasket kit
12	980933	2	Washer	
13	3853850	1	Circulation pump	
14	3856147	2	Stud, water pump	
15	3851991	1	V-belt pulley, crankshaft	PJX
16	3855717	3	Screw, pulley to crankshaft	PJX
17	3853390	4	Screw, water pump pulley to hub	
18	3852220	1	Pulley, water pump	
19	3856136	1	Bolt, water pump, short	
20	3858229	1	Sea water pump	Not for PJX
21	3852071	1	O-ring, thermostat	Part of engine gasket kit
22	3852098	2	Hose clamp, hose, thermostat hsg to water pump	
23	3856961	1	Thermostat, engine	
24	3852111	1	Gasket, thermostat hsg to engine	
25	3852288	1	Hose, thermostat hsg to water pump	
26	3853598	1	Elbow, thermostat hsg	Gi
	3850740	1	Plug	GL, GS
27	3852507	1	Stud, P/S bracket, pump	
28	3858241	1	Stay, stay, sea water pump	
29	3857954	1	Stop lug, stay, sea water pump	
30	3853266	2	Flange screw, stay bracket to engine	
31	3857939	3	Screw, pump pulley to engine	
32	3850397	1	Switch	GL, GS