



10973

| REF | PART NO. | QTY | DESCRIPTION | SEE SEC. | NOTES |
|-----|----------|-----|--------------------|----------|---|
| 1 | | 1 | cylinder block | | Included in basic engine, See group 10A |
| 2 | | 5 | • bearing cap | | |
| 3 | 835037 | 5 | • Screw | | |
| 4 | 835038 | 5 | • Stud | 12468 | |
| 5 | (818989) | 2 | • Locating pin | | Obsolete part |
| 6 | 835039 | 8 | • Expansion plug | | |
| 7 | 855828 | 2 | • Locating pin | | |
| 8 | 856230 | 4 | • Plug | | |
| 9 | 835040 | 2 | • Locating pin | | |
| 10 | 952075 | 5 | • Plug | | |
| 11 | 835496 | 1 | • Expansion plug | | |
| 12 | 841423 | 2 | • Bushing | | |
| 13 | 841424 | 2 | • Bushing | | |
| 14 | 841422 | 1 | • Bearing | | |
| 15 | 835497 | 4 | • Locating pin | | |
| 16 | 191026 | 1 | • Plug | | |
| 17 | | 8 | • piston | 12452 | |
| 18 | 940133 | 1 | • Hexagon screw | | |
| 19 | 18651 | 1 | • Gasket | | |
| 20 | 192134 | 2 | • Plug | | |
| 21 | | X | • main bearing kit | 12452 | |
| 22 | 841056 | 1 | Flywheel housing | | |
| 23 | 855909 | 1 | Cover plate | | |
| 24 | 947224 | 4 | Hexagon screw | | |
| 25 | 955541 | 2 | Hexagon screw | | L=76mm |
| | 955535 | 3 | Hexagon screw | | L=32mm |
| 26 | 942336 | 5 | Spring washer | | |