


5.8FSIPHUBCE, 5.8FSIPHUCCE, 5.8FSIPHUECE, 5.8FSIPHURCE, 5.8FSIPHUSCE



12673

5.8FSIPHUBCE, 5.8FSIPHUCCE, 5.8FSIPHUECE, 5.8FSIPHURCE, 5.8FSIPHUSCE

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852034	1	Retainer, Float to pin	
2	3854152	1	Valve, Reservoir assy	
3	3852453	1	Fitting, Cover, reservoir assy, return	
4	3852481	1	Grommet, Fuel pump to cover, reservoir assy	
5	3852506	1	Fitting, Pump to reservoir	Low pressure fuel pump
6	3853642	2	O-ring, Retainer, fuel pump	
7	3853572	1	Retainer, Fuel pump to cover	Reservoir assy
8	3853573	1	Bracket, Fuel pump grommet, reservoir assy	
9	3853574	1	Gasket, Cover, reservoir assy	
10	3853575	1	Float, Reservoir assy	
11	3853576	1	Spring seat, Float needle, reservoir assy	
12	3853577	1	Gasket, Float needle seat, reservoir assy	
13	3853578	1	Needle, Float, reservoir assy	
14	3853579	1	Clip, Needle to float, reservoir assy	
15	3853597	1	Elbow, Vent, reservoir to intake	
16	3852480	1	Elbow, Reservoir to thermostat hsg	
17	3853606	8	Screw, Cover to reservoir	Reservoir assy
18	3853616	1	Protective cap, Pressure valve	
19	3854280	1	Fuel pump, Electric	High pressure
20	3854149	1	Reservoir	
21	3852093	1	· Stud, Bracket & cooler mount	
22	3852167	1	· Plug, Reservoir drain	
23	3853544	1	Bracket, Support, fuel pump & relay mounting	
24		1	Breaker, Water temperature	Intake manifold, front
25	3854405	1	Cardboard tube, Reservoir	
26	3852001	2	Spring washer, Circuit breaker terminals	Fuel pump
27	3854158	1	Sensor, Air charge temperature	
28	3853913	1	Intake gasket kit, Intake manifold	
29	3852013	1	Elbow, Inlet, fuel filter cover	
30	3852064	2	Nut, Circuit breaker terminals	Fuel pump
31	3852208	2	Screw, Relay & cable assy	
32		2	Cable tie, Cable to fuel pump assy	
		1	Cable tie, Eng cbl to low pres fuel pump assy	
33	3853620	2	Hexagon screw, Circuit breaker to bracket	
34	3852481	1	Grommet, Fuel pump to bracket	
35		1	Inlet pipe	
36	3850861	1	Kit	
37	3851218	1	· Fuel filter	
38	3853545	1	Fitting, Fuel pump	
39	3850820	1	· O-ring, Fitting	
40	3853570	1	Bracket, Pump, filter, circuit breaker & support	
41	3854902	1	Fuel pump, Low pressure	
42	3854163	1	Automatic fuse, 20A, fuel pump	
43	3853036	1	Bolt, Intake manifold	
44		8	Injector	
45	3853733	1	O-ring	
46	3854154	1	Fuel pipe, Reservoir to fuel line, feed	
47	3854155	1	Fuel pipe, Regulator to reservoir	
48	3854165	1	Fuel pipe, Fuel pump to reservoir, low pressure	
49	3852043	1	Screw, Clamp & spacer to valve cover	
50	3853617	1	Bushing, Clamp, fuel line to volve cover	Port
51	3852231	1	Clamp, Fuel line to valve cover, port	
52	3853266	2	Screw, Fuel pump, support bracket,	Fuel filter to bracket
53	3853558	2	Screw, Fuel filter bracket to cyl head	
54	3854153	1	Fuel pipe, Fuel injectors to intake	
55		1	Regulator kit	
56	3853737	1	Gasket	
57	3853738	1	O-ring	
58		3	Screw	
59	3854152	4	Valve	
60	3853616	1	Protective cap	
61	3852259	1	Relay, Fuel pump	
62	3853493	1	Fitting, Fuel pump to fuel filter cover	

5.8FSIPHUBCE, 5.8FSIPHUCCE, 5.8FSIPHUECE, 5.8FSIPHURCE, 5.8FSIPHUSCE

REF	PART NO.	QTY	DESCRIPTION	NOTES
63	3850819	1	· O-ring, Fitting	
64	3854159	1	Sensor, Coolant temperature	
65	3852213	4	Screw, Fuel line assy to intake manifold	Fuel injectors
66	3852210	1	Bracket, Relay	
67		1	Wiring harness	
68	3853680	8	· Connector, Injector	
69	3853679	2	· Terminal	
70	3853708	1	Connector	
71		1	Retainer	
72		1	Terminal	
73	3853711	8	Receptacle, Injector	
74	3852230	1	Plug, Connector seal	
75		8	Terminal	
76	3850374	1	Kit, Fuel reservoir	