

| DESCRIPTION | SEE SEC. | NOTES |
|--------------------------------|----------|--|
| Serpentine Belt and Alternator | 5043 | 5.0GX _i -B, 5.0GX _i -BF, 5.0OS _i -B, 5.7Gi-B, 5.7Gi-BF, 5.7GX _i -C, 5.7GX _i -CF, 5.7OS _i -A, 5.7OS _i -AF, 5.7OSX _i -A, 5.7OSX _i -AF |
| Serpentine Belt and Alternator | 5044 | 5.7Gi-B, 5.7GX _i -C |
| Starter | 9652 | 5.0GX _i -B, 5.0GX _i -BF, 5.0OS _i -B, 5.0OS _i -BF, 5.7Gi-B, 5.7Gi-BF, 5.7GX _i -C, 5.7GX _i -CF, 5.7OS _i -A, 5.7OS _i -AF, 5.7OSX _i -A, 5.7OSX _i -AF |
| Starter | 5045 | 5.7Gi-B, 5.7GX _i -C |
| Electrical System | 5046 | 5.0GX _i -B, 5.0GX _i -BF, 5.0OS _i -B, 5.0OS _i -BF, 5.7Gi-B, 5.7Gi-BF, 5.7GX _i -C, 5.7GX _i -CF, 5.7OS _i -A, 5.7OS _i -AF, 5.7OSX _i -A, 5.7OSX _i -AF |
| Electrical System | 9653 | 5.7Gi-B, 5.7GX _i -C |
| Alarm and Circuit Breaker | 5047 | 5.0GX _i -B, 5.0GX _i -BF, 5.0OS _i -B, 5.0OS _i -BF, 5.7Gi-B, 5.7Gi-BF, 5.7GX _i -C, 5.7GX _i -CF, 5.7OS _i -A, 5.7OS _i -AF, 5.7OSX _i -A, 5.7OSX _i -AF |
| Alarm and Circuit Breaker | 9654 | 5.7Gi-B, 5.7GX _i -C |