

DESCRIPTION	SEE SEC.	NOTES
Crankcase	10628	5.8FIPNCACE, 5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FIPNCSCE, 5.8FSIINCC, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD, 5.8FSIPNCS
Crankcase	35424	5.8FLINCC, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCB, 5.8FLPNCM, 5.8FLPNCS
Cylinder Head	10630	5.8FIPNCACE, 5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FIPNCSCE, 5.8FSIINCC, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD, 5.8FSIPNCS
Cylinder Head	10631	5.8FLINCC, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCB, 5.8FLPNCM, 5.8FLPNCS
Deceleration Valve	10632	5.8FLINCC, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCB, 5.8FLPNCM, 5.8FLPNCS
Oil Pan and Oil Pump	10621	5.8FIPNCACE, 5.8FIPNCMCE, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCB, 5.8FLPNCM, 5.8FLPNCS, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD
Oil Pan and Oil Pump	35412	5.8FIPNCBCE, 5.8FIPNCSCE, 5.8FLINCC, 5.8FLPNCB, 5.8FLPNCS, 5.8FSIINCC, 5.8FSIPNCD, 5.8FSIPNCS
Oil Pan, Pump and Remote Filter	35414	5.8FSIINCC, 5.8FSIPNCS
Oil Pan, Pump and Remote Filter	10622	5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD
Remote Oil Filter	10697	5.8FIPNCACE, 5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FIPNCSCE, 5.8FLINCC, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCB, 5.8FLPNCM, 5.8FLPNCS, 5.8FSIINCC, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD, 5.8FSIPNCS
Flywheel Housing and Mounts	10614	5.8FIPNCACE, 5.8FIPNCSCE, 5.8FLINCS, 5.8FLPNCA, 5.8FLPNCS, 5.8FSIPNCACE, 5.8FSIPNCS
Flywheel Housing and Primary Shaft	10613	5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FLPNCB, 5.8FLPNCM
Inboard Mounting Components	10618	5.8FLINCC, 5.8FLINCS, 5.8FSIINCC, 5.8FSIINCS