


5.8FIPNCACE, 5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FIPNCSCE, 5.8FSIINCC, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD, 5.8FSIPNCS



5.8FIPNCACE, 5.8FIPNCBCE, 5.8FIPNCMCE, 5.8FIPNCSCCE, 5.8FSIINCC, 5.8FSIINCS, 5.8FSIPNCACE, 5.8FSIPNCD, 5.8FSIPNCS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852495	1	Spacer, P/S pump to bracket, rear	
2	3853330	1	Bracket, P/S pump to engine	
3	3852704	1	Bracket, P/S pump to engine	
4	3853660	1	Brace	
5	3853315	1	Fitting, Steering hose plug	
6		1	Clamp	
7	3853394	1	Screw	
8	3853405	1	Screw	
9	3852055	1	Spring washer	
10	3852116	1	Washer, Bracket to steering pump, front	
11	3853327	1	Bracket	
12	3853398	1	Screw, Clamp to cylinder head	
13	3852256	1	Hexagon screw, Bracket, pump to engine	
14	3852498	1	Nut	
15	3853331	1	V-belt, power steering pump	
16	3852497	1	O-ring, Pressure hose to steering pump	
17	3853580	1	Hose, Reservoir assy to oil cooler	
18	3853632	1	Hose, Oil cooler to steering pump, return	Fi/FSi
19	3853581	1	Hose, Cooler to therm. hsg	Fi/FSi
20	3853804	1	Pulley	
21	3852079	1	Nut, Oil cooler bracket	
22	3853236	1	Spacer	
23	3852126	1	Screw, Oil cooler & bracket assy	
24		1	Clamp, Hoses to valve cover	
25		1	Clamp	
26	3854204	1	Hose, Pump to cylinder	
	3853863	1	Hose, Pump to cylinder	
27	3854168	1	Hose assembly	Fi/FSi
28	3853557	1	Screw	
29		1	Cable tie	
30	3853406	1	Screw	
31	3852162	1	Washer, Spacer, oil cooler clamp to reservoir	Fi/FSi
32	3852161	1	Nut, Oil cooler to engine	
33	3853405	3	Screw, Steering pump bracket to steering pump	
34	3852700	1	Screw, Support tube to engine	
35	3852058	1	Washer	
36	3852599	1	Stud, Oil cooler to engine	
37	3852490	1	Clamp, Steering pump hoses to intake manifold	
38	3853780	2	Hose clamp, Water hoses	
39	3852196	2	Clamp, Oil hoses	
40	3850422	1	Hose clamp, Water to gimbal hsg	SX, DP-S
	3852602	1	Hose clamp, Water to gimbal hsg	290 DP
41	3851921	1	Oil cooler, PIS	
42	3852699	1	Tube, Bracket to engine	
43	3850491	1	Steering pump	