


500A, 501A, 501A/MS4



9632

500A, 501A, 501A/MS4

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	959046	X	Housing	
2		X	Protecting sleeve, RUBBER CAP	(841234)
	829200	X	Protective cap	D = 16 MM D = 14 MM
	76614	X	Rubber collar	D = 16 MM D = 6 MM
3	673580	X	Adapter	
4	941269	X	Plug	D = 25 MM
	821053	X	Protecting bushing	D = 35 MM
5	823759	X	Rubber bushing	
6		X	Bellows	
		X	Bellows	
7		X	Protective cap	L = 88 MM B = 32,5 MM
8		X	Isolation	BLACK, FOR (844280)
		X	Isolation	RED, FOR (844280)
9	847005	X	Sealing collar	L = 4,6 MM D = 3,0 MM
10	847005	X	Sealing collar	L = 100 MM D = 20 MM
11		X	Housing	1-WAY., FOR958208
12	947848	X	Housing, RECEPTACLE HOUSING	1-WAY., L = 20 MM
				H = 6 MM B = 7,8 MM
		X	Receptacle housing, RECEPTACLE HOUSING	1-WAY., L = 24 MM
				H = 7 MM B = 10,2 MM
	958208	X	Housing, RECEPTACLE HOUSING	1-WAY., FOR958207
				L = 24 MM H = 8,2 MM B =
	949597	X	Housing	1-WAY., L = 24,5 MM
				H = 6,1 MM B = 8,8 MM
	943511	X	Housing, PROTECTING SLEEVE	1-WAY., L = 24 MM
				H = 7,4 MM, B = 10 MM
13	1578937	X	Housing	2-WAY
14	958210	X	Housing	2-WAY
15	945469	X	Housing	3-WAY., L = 23 MM
		X	Housing, RECEPTACLE HOUSING	3-WAY., L = 24 MM
				FOR881485
16		X	Receptacle housing	3-WAY.
17	1214948	X	Housing	5-WAY.
18	958213	X	Housing	4-WAY.
19	958212	X	Housing	4-WAY.
20		X	Housing	8-WAY.
21	941105	X	Housing	8-WAY.
22	945830	X	Housing	11-WAY.
23	945831	X	Tab housing	11-WAY.
24	944077	X	Housing	8-WAY.
		X	Receptacle housing	FOR TRIM INSTRUMENT., 9-POLE
	948294	X	Housing, INSULATOR	9-POL
				INCL.IN 853032
25	948995	X	Housing	2-WAY.
26	846615	X	Sealing ring	
27	846612	X	Housing	16-WAY
28	846613	X	Unloading cable	
29	846647	X	Block	16-WAY
30	846613	X	Unloading cable	
31	1608765	X	Insulator	FOR 965824
32	1608766	X	Seal	FOR 1608765
33	1598753	X	Isolation	FOR 949371
34	1307048	X	Housing	
35	1307049	X	Housing	
36	846611	X	Housing	
37	853498		Receptacle housing, INSULATOR	3-POL
				INCL.IN 853032