


DPX385XLKE, DPX415XLKE



DPX385XLKE, DPX415XLKE

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852034	1	Retainer, Float pin	
2	3854152	1	Valve, Reservoir assy	
3	3852462	1	Fitting, Fuel line to reservoir	
4	3854517	1	Pressure sensor	
5	3852481	1	Grommet, Fuel pump to cover	Reservoir assy
6	3852017	1	Adapter, Fuel line	LP pump to reservoir
7	3853642	2	O-ring, Retainer, fuel pump	
8	3853572	1	Hollow screw, Fuel pump to cover	Reservoir assy
9	3853573	1	Bracket, Fuel pump grommet	Reservoir assy
10	3853574	1	Gasket, Cover	Reservoir assy
11	3853575	1	Float, Reservoir assy	
12	3853576	1	Seat, Float needle	Reservoir assy
13	3853577	1	Gasket, Float needle seat	Reservoir assy
14	3853578	1	Needle, Float	Reservoir assy
15	3853579	1	Clip, Needle to float	Reservoir assy
16	3853597	1	Elbow, Vent, reservoir to intake	
17	3852480	1	Riser, Reservoir to thermostat hsg	
18	3853606	8	Screw, Cover to reservoir	Reservoir assy
19	3853616	1	Protective cap, Pressure valve	
20	3855958	1	Fuel pump, High pressure	
21	3853558	2	Flange screw	
22	3854149	1	Tank	
23		1	· Plug, Reservoir assy	
	3852167	1	· Plug, Reservoir drain	
24	3856439	1	Bracket, Fuel filter and fuel pump	
25	3852029	1	Sender, Water temperature	
	872068	1	Sender, Water temperature, dual station	
26	3854405	1	Cover, Reservoir assy	
27	3852001	2	Lock washer, Circuit breaker	
28	3852108	1	Clamp, Distributor to engine	
29	3854095	1	Inlet gasket kit, Intake manifold	GSi, DPX
30	3852013	1	Elbow, Inlet, fuel filter cover	
31	3852064	2	Nut, Circuit breaker	
32	3852208	2	Screw, Relay & cable assy	
33		2	Lock strap, Engine cable to fuel pump	
34	3853620	2	Screw, Circuit breaker to bracket	Electrical ignition
35	3852481	1	Grommet, Fuel pump to bracket	
36		1	Manifold, Lower	GSi, DPX
37	3852109	1	Gasket, Distributor	
38	3850861	1	Cover	
		1	· Cover, Fuel filter	
39	3851218	1	· Fuel filter	
40	3853494	1	Fitting, Fuel line to fuel pump	
41	3850820	2	· O-ring, Fitting	
42	3854377	2	Bracket, Cylinder head	
43	3854902	1	Fuel pump, Low pressure	
44	3854162	1	Breaker, 12.5A	
45	3854654	4	Screw, Intake manifold, long	
46	3854853	1	Hose, Vapor separator to oil cooler	
47	3854518	8	Injector	
48	3855192	16	O-ring, Fuel injector	
49	3855191	8	Clip, Fuel injector	
50	3854646	1	Fuel pipe, Fuel regulator to reservoir	
51		1	Fuel pipe, Low pressure pump to reservoir	
52	3852077	2	Nut, Relay to fuel pump mtg. brkt	
53	3853273	2	Lock nut, Stud, bracket to cylinder head	
54	3852117	1	Stud, Lift bracket & fuel pump bracket	
55	3853393	1	Screw, Fuel filter, oil tube, & spacer to brkt	
56	3854515	8	O-ring, Manifold	
57	3852098	1	Clamp, Hose to gimbal	
58	3850657	2	Nut	
59	3854574	1	Fuel pipe	
60		2	· Plug, Fuel rail, 1/16-27 NPTF	

DPX385XLKE, DPX415XLKE

REF	PART NO.	QTY	DESCRIPTION	NOTES
61	3855033	4	· Plug, Fuel rail, 1/8-27 NPTF	
62		1	Fuel pipe	
63	3852115	1	Screw, Pressure regulator to fuel rail	
64	3853616	2	Protective cap, Pressure valve	
65	3854152	1	Valve, Fitting, HP fuel pump to fuel line	
66	3850403	1	Relay, Fuel pump	
67	3853493	1	Fitting, Fuel pump to fuel filter cover	
68	3850819	1	O-ring, Fitting, fuel pump to cover	Fuel filter
69	3850397	1	Switch	
70		4	Screw, Fuel rail to lower manifold	
71	3852210	1	Bracket, Relay	
72	3852495	1	Spacer, Clamp, oil tube to fuel filter bracket	
73	3854924	1	Fitting, Valve	HP fuel pump
74	3855190	1	O-ring	
75	3852602	1	Clamp, Hose to reservoir	
76	3850374	1	Sealing kit, Fuel reservoir	
77	3853537	2	Protective cap, Breaker assy, fuel pump	
78	3853261	1	Clamp, Oil withdrawal tube to fuel filter brkt	
79	3852129	1	Nut, Screw, fuel filter assy to bracket	
80	3853557	1	Screw, Distributor clamp to engine	
81	3852196	3	Clamp, Antisiphon valve	
82	3850653	1	Hose, Antisiphon valve to reservoir	
83	3854673	1	Hose, Antisiphon valve to therm. hsg	
84	3854925	1	Clamp, Hose, antisiphon valve from reservoir	
85	3850666	1	Nipple, Antisiphon	
86	3852017	1	Adapter, Fuel line to fuel rail	
87	3854582	1	Bracket, Reservoir to flywheel hsg	Gi SX, GSi SX
	3850271	1	Bracket, Reservoir to flywheel hsg	SX, DP-S