



9942

740A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	856609	1	Water pump		
			COMPONENTS		
2	856610	2	Gasket		
3	955536	4	Screw		
4	856611	1	Hose		
5	856612	2	Hose attachment		
6	961666	2	Hose clamp		
7	855283	1	Pulley		
8	955656	4	Screw		
9	941907	4	Spring washer		
10	856513	1	Sea water pump		
				02B-0410	
11	956594	3	Screw		
12	942336	3	Spring washer		
13	856155	1	Bracket		
14	940134	2	Screw		
15	941909	2	Spring washer		
16	826422	1	Rubber bushing		
17	955523	1	Screw		
18	960141	1	Washer		
19	941907	1	Spring washer		
20	855993	1	Thermostat housing		
21	876305	1	Thermostat kit		62%Z9C
22	416033	1	· Sealing ring	IK	
23	835417	1	· Gasket	IK	
24	856262	1	Hose		
25	961671	2	Hose clamp		
26	856310	1	Tube		
26A	943717	1	Clamp		
26B	946440	1	Flange screw		SEE GROUP 3
27	940115	2	Screw		
28	942336	2	Spring washer		
29	856222	1	Tube		
30	952973	X	Hose		L = 2X70 MM
31	856268	1	Tube		EARLY TYPE
	857051	1	Hose		LATE TYPE
32	858587	1	Bracket		
33	940133	1	Screw		
34	942336	1	Spring washer		
35	943717	2	Clamp		
36	946544	2	Flange screw		
37	945407	2	Flange nut		
38	952973	X	Hose		L = 100 MM
39			HOSES AND OIL COOLER FOR POWER STEERING		SEE GROUP 6
40	856505	1	Hose		ENGINE WITH DRIVE UNIT WITHOUT POWER STEERING.
41	854489	1	Hose		SEE GROUP 4A. FOR SHIELD KIT 876150.
	857048	1	Hose		SEE GROUP 4A. FOR SHIELD 876506.. FOR SHIELD 876510.
42	961669	20	Hose clamp		
43	855987	1	Tube		
44	855986	1	Tube		
45	952973	X	Hose		L = 100 MM
46	858986	2	Sealing ring		
47	842913	2	Sealing ring		
48	965175	4	Screw		
49		1	OIL COOLER		SEE GROUP 2A
50		1	CONNECTION		SEE GROUP 2A
51	856263	1	Bracket		
52	856314	1	Clamp		

740A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
53	946440	1	Flange screw		
54	955526	2	Screw		
55		1	CONNECTION		SEE GROUP 2A
56	967191	1	V-belt set, DRIVE BELT KIT		SEE GROUP 3
					L = 2X1275 MM
57		2	EXHAUST MANIFOLD	02B-0250	
			SERVO PUMP		SEE GROUP 6