



5362

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1		1			
2		1	• PANEL		SIDE MOUNTING.
3		1	• Tachometer		
4	841233	1	• Thermometer		(831475)
5	824963	1	• Starter switch		
6		2	• • Key		ÅKERMAN SPEC. 867477.
			• Bulletin P-36-4-1	P-36-4-1-EN	Deleted Part No's for Keys
7		1	• Collar		
8		1	• Nut		
9		2	• Switch		
		2	• Knob		
10					
12		2	• E-circlip		
13	827766	2	• Lens		
14	19923	4	• Bulb		
15	819350	2	• Sleeve		
16	808175	2	• Lamp socket		
17		2	• Lamp socket		
18	944540	4	• Screw		
19		1	• Cable trunk		
		X	• • CABLES AND CABLE TERMINALS	12858	
20	827353	X	• Cable tie		