



5943

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	463630	1	Cylinder head		
	3803018	1	Cylinder head, exch		Exchange unit
2	419652	4	· Valve guide		
3	463771	4	· Valve guide		
4		4	· VALVE SEAT, INTAKE		STD
	1219095	4	· Valve seat, INTAKE		OVER SIZE 0,5 MM
5		4	· VALVE SEAT, EXHAUST		STD
	1219096	4	· Seat ring, EXHAUST		OVER SIZE 0,5 MM
6		5	· BEARING CAP	02A-0650	
7	463690	10	· Guide sleeve		
8	953049	10	· Stud		
9	941907	10	· Spring washer		
10	955782	10	· Nut		
11	191026	2	· Plug		
12	946779	2	· Cap plug		
13	946780	4	· Cap plug		
14	946778	1	· Cap plug		
15	952076	1	Plug		
18	953046	8	Stud		SEE GROUP 2B
19	948564	1	Stud		L = 50 MM, SEE GROUP 2B
	948606	1	Stud		MO-608/XXXX.
	963196	1	Screw		L = 52 MM, SEE GROUP 2B
20	953077	1	Stud	02A-0900	MO609/XXXX-.
21	463390	1	Stud	02A-0900	
22	463412	1	Gasket	IK	
23	953040	10	Stud		
24	463999	1	Gasket	IK	
25	463416	1	Seal	IK	
26	1276327	1	Valve cover		(1219719)
27	941906	9	Spring washer		
28	948685	10	Nut		(190566)
29	1306341	10	Screw		(945797)
30	420292	1	Oil filler cap		
31	940096	1	Gasket	IK	