



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	1346408	1	Cylinder head		
2	419652	4	· Valve guide, INTAKE	02A-0750	
3	463771	4	· Valve guide, EXHAUST	02A-0750	
4		4	· VALVE SEAT INTAKE		STD
	1266418	4	· Seat ring		OVER SIZE 0,50 MM
5		4	· VALVESEAT EXHAUST		STD
	1266421	4	· Seat ring		OVER SIZE 0,50 MM
6		5	· BEARING CAP	02A-0750	
7	463690	10	· Guide sleeve	02A-0750	
8	953049	10	· Stud		
9	945408	10	· Flange nut		
10	940375	2	· Plug		
11	946779	2	· Cap plug		
12	946780	4	· Cap plug		
13	946778	1	· Cap plug		
14	968145	1	· Plug		
15	968145	1	Plug		
16	953046	6	Stud		
17	953077	1	Stud	02A-0960	
18	463390	1	Stud	02A-0960	
19	1378646	1	Gasket	IK	
20	953035	10	Stud		
21	1378870	1	Gasket	IK	
22	1336754	1	Valve cover		
24	968458	10	Nut		
25	1306341	10	Screw		
26	1378985	1	Oil filler cap		
27	940096	1	Gasket	IK	
28	1336763	1	Cover		
29	855583	1	Ring		
31	855731	1	Belt protector		AQ151B, SERIAL NO 9190-