



9596

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	852851	1	Intermediate housing	
2	897829	1	· Gear yoke	
3	897447	1	· Shaft	
4	897511	2	· Washer	
5	17253	1	· Cotter pin	IK
6	851412	1	· Reverse locking rod	
7	967556	1	· · Spring pin	
8	852869	1	Suspension fork	
9	940194	1	· Nipple	
10	852912	2	· Bushing	
11	853062	1	· Bushing	
12	853223	2	Bushing	
13	183391	1	Needle bearing	
14	181620	2	Sealing ring	IK
15	853310	1	Cylinder anchorage	
16		1	· SHAFT	
17	853308	2	Shoulder screw	
18	853071	2	Washer	
19	946672	2	Lock nut	
20	853309	2	Clevis pin	
21	967707	2	Cotter pin	
22	814386	1	Tube	
23	897696	2	Washer	
24	851766	1	Hose connection	
25	814356	1	Seal	IK
26	941813	2	Screw	
27	853078	1	Cable attachment	
28	940168	2	Screw	
29	897644	1	Tube	
30	851422	1	Reverse tilt inhibit	
31	851402	1	· Bearing sleeve	
32	814391	2	· Reverse tilt inhibit	
33	814392	1	· Spring hook	IK
34	814419	1	· Shaft	IK
35	814422	2	· Spacer washer	IK
36	814393	1	· Spring hook	IK
37	943197	2	· Nut	IK
38	851424	1	· Stop arm	IK
39	832534	1	· Spring	IK
40	851403	1	· Lock brace	
41	851423	2	· Pin	
42	814396	1	· Spring	IK
43	814332	2	· Spring	IK
44	814399	1	· Shaft	IK
45	943194	2	· Washer	IK
	876075	1	Repair kit, ASTERN LEVER	
46	814390	1	Washer	IK
47	804312	1	Cube	
48	940191	2	Washer	
49	17276	1	Cotter pin	
50	925259	1	O-ring	IK
51	125017	2	O-ring	IK
52	943252	X	Adjusting washer	TH = 0,05 MM
	943866	X	Adjusting washer	TH = 0,10 MM
	943867	X	Adjusting washer	TH = 0,20 MM
	967557	X	Adjusting washer	TH = 0,30 MM
	943868	X	Adjusting washer	TH = 0,40 MM
53	941807	2	Screw	
54	941885	2	Nut	
55	941816	2	Screw	IK
56	897448	1	Control rod	
57	813954	1	Control fork	
58	192662	1	Clevis pin	SEE GROUP 9

