



8852

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	854027	1	Intermediate housing	
2	897829	1	• Gear yoke	
3	814397	1	• Coupling rod	
4	897447	1	• Shaft	
5	897511	1	• Washer	
6	17253	1	• Cotter pin	
7	925259	1	O-ring	IK
8	943252	X	Adjusting washer	TH = 0,05 MM
	943866	X	Adjusting washer	TH = 0,1 MM
	943867	X	Adjusting washer	TH = 0,2 MM
	967557	X	Adjusting washer	TH = 0,30 MM
	943868	X	Adjusting washer	TH = 0,4 MM
9	875365	1	Suspension fork	
10	940194	1	• Nipple	
11	814388	1	• Bushing	
12	183391	1	• Needle bearing	
13	181620	2	• Sealing ring	IK
14	959456	2	Allen head screw	
15	942551	2	Washer	
16	814390	2	Washer	ALT
17	941885	2	Nut	
18	897448	1	Control rod	
19	813954	1	Control fork	
20	940190	1	Nut	
21	192662	1	Clevis pin	
22	17253	2	Cotter pin	IK
23	814386	1	Tube	
24	941820	1	O-ring	IK
25	897696	1	Washer	
26	941809	1	Screw	
27	941808	2	Screw	
28	851766	1	Hose connection	REPL BY 854031 SEE GROUP 4A
29	814356	1	Seal	IK
30	941813	2	Screw	
33	897644	1	Tube	
34	125017	2	O-ring	IK
35	897457	1	Cable attachment	
36	940168	2	Screw	
37	940191	2	Washer	
38	826341	2	Bushing	
39	804312	1	Cube	
40	907834	1	Cotter pin	(17276)
41	940191	2	Washer	
42	814434	1	Reverse tilt inhibit	
43	814391	2	• Reverse tilt inhibit	
44	814389	1	• Bearing sleeve	
45	814422	2	• Spacer washer	IK
46	852046	1	• Push rod	(814421)
46B		1	• • NUT	(940197)
47	897722	1	• Thrust sleeve	
48	814394	1	• Lock brace	
49	814395	2	• Pin	
50	832534	1	• Spring	IK
51	814399	1	• Shaft	IK
52	943194	1	• Washer	IK
53	814392	1	• Spring hook	IK
54	814419	1	• Shaft	IK
55	814393	1	• Spring hook	IK
56	943197	2	• Nut	IK
57	814398	1	• Shaft	IK
58	814396	1	• Spring	IK
59	814332	2	• Spring	IK
60		X	CONTROL CABLE	SEE GROUP 9

REF	PART NO.	QTY	DESCRIPTION	NOTES
61	941807	2	Screw	
62	853716	1	Decal	
63	853717	1	Decal	
	875361	1	Repair kit, REPAIR KIT ASTERN LEVER	