



ENGINE WIRE HARNESS, GL

REF	PART NO.	QTY	DESCRIPTION
1	3860036	1	Cable harness
2	3852527	2	Cable terminal, Engine ground
3	3852084	1	Cable terminal, Oil pressure switch
4	3853320	1	Cover, Oil pressure switch
5	3852233	1	Cable terminal, Oil pressure switch
6	3852233	1	Cable terminal, AC tap
7	3852235	1	Cable terminal, Alternator excite
8	3852245	1	Cable terminal, Alternator ground
9	3852233	1	Cable terminal, Alternator ind light
10	3852130	2	Rubber cap
11	3852038	1	Cable terminal, Alternator output
12	3852235	1	Cable terminal, Alternator sense
13	3852084	1	Cable terminal, Water temp switch
14	3853320	1	Cover, Water temp switch
15	3852233	1	Cable terminal, Starter solenoid
16	3852235	1	Cable terminal, Starter solenoid, starter terminal
17	3852527	1	Cable terminal, Starter solenoid
18	3852527	1	Cable terminal, Starter solenoid
19	3852064	2	Nut, Circuit breaker
20	3852001	2	Lock washer, Circuit breaker
21	3854164	1	Fuse, 50 amp
22	3852245	1	Cable terminal, Circuit breaker to splice
23	3854192	1	Connector, Starter relay
24	3852254	4	Cable terminal, Starter relay
25	3852227	1	Cable terminal, Ground electrical bracket
26	3854192	1	Connector, Starter relay
27	3852254	4	Cable terminal, Starter relay
28	3852084	1	Cable terminal, Choke
29	3852220	1	Pulley, Choke
30	3852233	1	Cable terminal, Water temp transmitter
31	3852210	1	Bracket
32	3850403	1	Relay
33	3852246	3	Cable terminal
34	3852247	1	Cable terminal, Fuel pump
35	3853679	2	Cable terminal, Fuel pump
36	916453	1	Fuel pump
37	916127	1	Fuel pump
38	3854244	1	Cable, Ignition coil dist terminal
39	3853565	1	Connector, Trim sender
40	3852229	1	Cable terminal, Trim sender
41	979686	1	Fuse, 40 amp
42	969197	1	Fuse, 7.5 amp
43	3860455	2	Fuse holder