



# OIL PAN & LUBRICATION

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852822	1	Gasket, Oil pan	5.0 liter model
	3852823	1	Gasket, Oil pan	5.8 liter model
2	3853070	1	Retainer, Oil pump shaft	5.0 liter model
	3853005	1	Retainer, Oil pump shaft	5.8 liter model
3	3853006	4	Screw, Oil pan	
4	3853032	2	Screw, Pickup tube	
6	3853033	18	Screw, Oil pan	
7	3853797	1	Oil pan	5.0 liter model
	3850394	1	Oil pan	5.8 liter model
	3853034	1	· Plug, Oil indicator hole	5.8 liter model
8	3853069	1	Oil pump screen, Oil pump'	5.0 liter model
	3853104	1	Oil pump screen, Oil pump	5.8 liter model
9	3853068	1	Shaft, Oil pump	5.0 liter model
	3853105	1	Shaft, Oil pump	5.8 liter model
10	3853071	1	Reinforcement, Oil pan, stbd	5.0 liter model
	3853106	1	Reinforcement, Oil pan, stbd	5.8 liter model
11	3853072	1	Reinforcement, Oil pan, port	5.0 liter model
	3853107	1	Reinforcement, Oil pan, port	5.8 liter model
12	3853909	1	Oil pump	5.0 liter model
	3853908	1	Oil pump	5.0 liter model
13	3854145	1	Tube, Oil drain	5.0 liter model
	3854170	1	Tube, Oil drain	5.8 liter model
14	3850474	1	Oil dipstick	5.0 liter model
	3850473	1	Oil dipstick	5.8 liter model
15	3851981	1	Sealing washer, Fitting	5.0 liter model
	3853725	1	Sealing washer, Fitting	5.8 liter model
16	3852694	1	Hollow screw, Oil drain	5.0 liter model
	3852609	1	Hollow screw, Oil drain	5.8 liter model
17	3855112	1	Fitting, Oil drain	
18	3853674	1	O-ring, Oil drain	
19	3852007	1	Washer, Retainer	
20	3853267	1	Gasket, Oil screen	
21	3852788	2	Screw, Oil pump to block	
22	3852033	1	O-ring, Oil drain tube	