



ENGINE WIRE HARNESS, FL

REF	PART NO.	QTY	DESCRIPTION
1	3850408	1	Cable harness
2	3852233	1	· Cable terminal, A.C. tap
3	3852107	1	· Cable terminal, Bracket ground
4	3852227	2	· Cable terminal, Flag
5	3852038	1	· Cable terminal, Alternator output
6	3852130	2	· Rubber cap
7	3852229	2	· Cable terminal, Pin
8	3853320	2	· Cover, Terminal
9	3852233	10	· Cable terminal
10	3853565	1	· Connector
11	3850998	2	· Cable terminal, Ground
12	3850992	1	· Connector
13	3852257	1	· Cable terminal, Socket
14	3852244	2	· Cable terminal
15	3852248	2	· Cable sleeve
16	3852181	2	· Cap
17	3852245	1	· Cable terminal, Circuit breaker
18	3852235	1	· Cable terminal
19	3850991	1	· Connector
20	3852064	2	Nut, Assist solenoid
21	3852042	2	Nut, Assist solenoid
22	3853974	1	Cable, Circuit breaker to breaker
23	3852235	2	· Cable terminal
24	3852064	4	Nut, Circuit breaker
25	3853975	1	Cable, Solenoid to circuit breaker
26	3852037	1	· Cable terminal
27	3852235	1	· Cable terminal
28	3852208	3	Screw, Cable retainer
29	3853620	4	Screw, Circuit breaker
30	3852001	2	Lock washer, Assist solenoid
31	3852001	4	Lock washer, Circuit breaker
32	3852055	2	Washer, Assist solenoid
33	3850455	1	Bracket, Engine cable
34	3852825	1	Retainer, Engine cable
35	3853786	1	Clamp, Instrument cable
36	3852487	2	Protective cap, Battery cable
37	3853939	1	Cable, Starter solenoid
38	3853839	1	Solenoid, Starter assist
39	3854164	2	Fuse, 50 amp
40	3852194	2	Screw, Assist solenoid
44	3852237	1	Retainer, Trim sender