



FLYWHEEL HOUSING & MOUNTS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852831	1	Flywheel housing	
2	3854604	1	Cover	
3	3852834	1	Gasket, Flywheel cover	Part of engine gasket kit
4	3852832	1	Hose, Flywheel hsg	
5	3852421	7	Screw, Flywheel cover to housing	
6	3853266	1	Screw, Flywheel hsg to engine	Port
7	3852070	2	Washer, Ground stud, flywheel housing	
8	3852058	2	Washer, Ground stud, flywheel housing	
9	3852760	2	Bracket, Front, port & starboard	
10	959968	4	Screw, Rear mount to transom plate	
11	3853806	2	Rubber cushion, Transom plate	
12	3852155	4	Washer, Rear mount to transom plate	
13	3850930	2	Screw, Rear mount	
14	3850929	2	Nut, Rear mount	
15	3852540	2	Washer, Rear mount to flywheel hsg	
16	3852539	2	Nut, Rear mount	
17	3852622	2	Washer, Rear mount	
18	3852475	4	Screw, Engine to boat stringers	
19	3852078	4	Washer, Engine to boat stringers	
20	3852542	2	Washer, Rear mount	