



ALTERNATOR

REF	PART NO.	QTY	DESCRIPTION	NOTES
	3853853	1	Alternator, 5.7GL	5.7 GL
	3854182	1	Alternator, 5.7Gi	5.7 Gi
1	3852647	1	· Housing, Front	
2	3853838	1	· Rotor	5.7 GL
	3854226	1	· Rotor	5.7 Gi
3	3853837	1	· Stator	5.7 GL
	3854225	1	· Stator	5.7 Gi
4	3852646	1	· Housing, Rear	
5	3852645	1	· Fan	5.7 GL
	3853756	1	· Fan	5.7 Gi
6	3852644	1	· Pulley	5.7 GL
	3853755	1	· Pulley	5.7 Gi
7	3852643	2	· Bearing, Front & rear	
8	3852624	2	· Isolation, Red	5.7 GL
9	3852623	1	· Isolation, Boot	5.7 GL
10	3852642	1	· Bearing carrier, Rear bearing	
11	3852641	1	· Diode	
12	3853836	1	· Diode bridge	
13	3852640	1	· Plate, B+	
14	3853835	1	· Brush retainer	
15	3852639	1	· Spacer, Fan	
16	3852638	1	· Key, Woodruff	
17	3852637	1	· Gasket	
18	3853834	1	· Cover	
19	3852636	1	· Capacitor	5.7 GL
20	3852635	1	· Plate, AC tap	
21	3852625	1	· Lock washer, Pulley	
22	3852736	1	· Screw, Capacitor	
23	3852630	1	· Nut, Pulley	
24	3853833	1	· Regulator, Voltage	5.7 GL
	3853757	1	· Regulator, Voltage	5.7 Gi
25	3852634	4	· Screw, Through	
26	3852734	4	· Screw, Front housing	
27	3852629	2	· Screw, Regulator	
28	3852736	1	· Screw, Alternator ground	
29	3852735	8	· Screw, Diode field	
30	3852628	3	· Screw, Diode field	
31	3852633	2	· Nut	
32	3852632	9	· Lock nut	
33	3852732	2	· Washer, Insulator	
34	3852626	5	· Washer	
35	3853881	1	· Cover plate	5.7 GL
36	3852737	1	· Screw, Terminal	
37	3853403	1	Nut, Alternator brace to pump	
38	3853367	1	Screw, Alternator to bracket	
39	3853547	2	Screw, Bracket	
40	3852058	1	Washer, Screw alternator	
41	3852069	1	Washer, Ground	
42	3852051	1	Nut, Alternator to bracket	
43	3853883	1	Bracket, Alternator	
44	3852740	1	· Bushing, Alternator	
45	3853396	1	Screw, Brace to alternator	
46	3852761	1	Brace, Alternator	
47	3852054	1	Washer, Brace to alternator	
48	3852185	1	Nut, Alternator excite wire	5.7 Gi
49	3852001		Lock washer, Alternator excite wire	5.7 Gi