


# FUEL SYSTEM & INTAKE MANIFOLD - 5.7 Gi



# FUEL SYSTEM & INTAKE MANIFOLD - 5.7 Gi

| REF | PART NO. | QTY | DESCRIPTION                        | NOTES                               |
|-----|----------|-----|------------------------------------|-------------------------------------|
| 1   | 3852034  | 1   | Retainer, Float pin                | Contents of Fuel Reservoir Seal Kit |
| 2   | 3854152  | 1   | Valve, Pressure, reservoir         |                                     |
| 3   | 3852017  | 1   | Adapter, Fuel pump to reservoir    |                                     |
| 5   | 3852481  | 1   | Grommet, Fuel pump, reservoir      |                                     |
| 6   | 3852462  | 1   | Fitting, Return to reservoir       |                                     |
| 7   | 3853642  | 2   | O-ring, Retainer, fuel pump        | Contents of Fuel Reservoir Seal Kit |
| 8   | 3853572  | 1   | Hollow screw, Fuel pump to cover   |                                     |
| 9   | 3853573  | 1   | Bracket, Fuel pump grommet         |                                     |
| 10  | 3853574  | 1   | Gasket, Cover, reservoir           | Contents of Fuel Reservoir Seal Kit |
| 11  | 3853575  | 1   | Float, Reservoir                   |                                     |
| 12  | 3853576  | 1   | Seat, Float needle                 | Contents of Fuel Reservoir Seal Kit |
| 13  | 3853577  | 1   | Gasket, Float needle seat          | Contents of Fuel Reservoir Seal Kit |
| 14  | 3853578  | 1   | Needle, Float                      | Contents of Fuel Reservoir Seal Kit |
| 15  | 3853579  | 1   | Clip, Needle to float              |                                     |
| 16  | 3853597  | 1   | Elbow, Vent, reservoir to intake   |                                     |
| 17  | 3852167  | 1   | Plug, Reservoir drain              |                                     |
| 18  | 3853606  | 8   | Screw, Cover to reservoir          |                                     |
| 19  | 3853616  | 1   | Protective cap, Pressure valve     |                                     |
| 20  | 3854280  | 1   | Fuel pump, High pressure           |                                     |
| 21  | 3854149  | 1   | Tank                               |                                     |
| 22  | 3852093  | 1   | · Stud, Oil cooler bracket         |                                     |
| 23  | 3852480  | 1   | Riser, Reservoir to thermostat     |                                     |
| 24  | 3853544  | 1   | Bracket, Support                   |                                     |
| 26  | 3854405  | 1   | Cover                              |                                     |
| 27  | 3852001  | 2   | Lock washer, Circuit breaker       |                                     |
| 29  | 3854269  | 1   | Gasket kit, Intake manifold        |                                     |
| 30  | 3852013  | 1   | Riser, Fuel line to pump           |                                     |
| 31  | 3852064  | 1   | Nut, Circuit breaker               |                                     |
| 32  | 3852208  | 1   | Screw, Relay, to support           |                                     |
| 33  | 3852158  | 2   | Lock strap, Cable                  |                                     |
| 34  | 3853620  | 2   | Screw, Circuit breaker             |                                     |
| 35  | 3852481  | 1   | Grommet, Fuel pump bracket         |                                     |
| 36  | 3854532  | 1   | Inlet pipe                         |                                     |
| 38  | 3850861  | 1   | Cover                              |                                     |
| 39  | 3851218  | 1   | · Fuel filter                      |                                     |
| 40  | 3853494  | 2   | Fitting, Fuel line to fuel pump    |                                     |
| 41  | 3850820  | 1   | · O-ring, Fitting                  | Contents of Fuel Reservoir Seal Kit |
| 42  | 3853570  | 1   | Bracket, Fuel pump & filter        |                                     |
| 43  | 3854902  | 1   | Fuel pump, Low pressure            |                                     |
| 44  | 3854163  | 1   | Breaker, 20A Fuel pump             |                                     |
| 48  | 3853733  | 16  | · O-ring, Fuel injector            |                                     |
| 49  | 3850277  | 1   | Fuel pipe, Pump to TBI             |                                     |
| 50  | 3850278  | 1   | Fuel pipe, TBI to reservoir        |                                     |
| 51  | 3854140  | 1   | Fuel line, Fuel pump to reservoir  |                                     |
|     | 3854165  | 1   | Fuel line, Fuel pump to reservoir  |                                     |
| 52  | 3852043  | 1   | Screw, Clamp & spacer, fuel line   |                                     |
| 53  | 3853617  | 1   | Sleeve, Fuel line to valve cover   |                                     |
| 54  | 3852231  | 1   | Clamp, Fuel line to valve cover    |                                     |
| 55  | 3853266  | 1   | Screw, Fuel filter bracket         |                                     |
| 56  | 3853558  | 1   | Screw, Bracket to head             |                                     |
| 65  | 3853616  | 1   | · Protective cap, Pressure valve   |                                     |
| 66  | 3852259  | 1   | Relay, Fuel pump                   |                                     |
| 67  | 3853493  | 1   | Fitting, Filter outlet to pump     |                                     |
| 68  | 3850819  | 1   | · O-ring, Fitting                  |                                     |
| 69  | 3852029  | 1   | Sender                             |                                     |
| 70  | 3852213  | 4   | Screw, Fuel rail assy              |                                     |
| 71  | 3852210  | 1   | Bracket, Relay                     |                                     |
| 82  | 3850374  | 1   | Sealing kit, Fuel reservoir        |                                     |
| 84  | 3850270  | 1   | Adapter, TBI                       |                                     |
| 85  | 3852196  | 1   | Clamp, Hose to reservoir           |                                     |
| 86  | 3853580  | 1   | Hose, Reservoir to oil cooler      |                                     |
| 87  | 3853419  | 3   | Screw, Engine cable to manifold    |                                     |
| 88  | 3850228  | 1   | Bracket, Throttle cable            |                                     |
| 89  | 3850405  | 1   | Gasket, Adapter to intake manifold |                                     |

# FUEL SYSTEM & INTAKE MANIFOLD - 5.7 Gi

| REF | PART NO. | QTY | DESCRIPTION                       | NOTES |
|-----|----------|-----|-----------------------------------|-------|
| 90  | 3850355  | 1   | Gasket, TBI to adapter            |       |
| 91  | 3850276  | 1   | Fuel pipe, Pump to reservoir      |       |
| 92  | 3850297  | 1   | Lever, throttle cable to TBI      |       |
| 93  | 3852142  | 3   | Nut, TBI to adapter               |       |
| 94  | 3852009  | 1   | Nut, Throttle lever               |       |
| 95  | 3852420  | 1   | Lock nut, Throttle lever          |       |
| 96  | 3853622  | 1   | Pin, Foat hinge                   |       |
| 97  | 3852008  | 4   | Screw, Adapter to manifold        |       |
| 98  | 3852048  | 1   | Screw, Throttle bracket           |       |
| 99  | 3852115  | 1   | Screw, Fuel line clamp            |       |
| 100 | 3853399  | 1   | Screw, Throttle lever upper       |       |
| 102 | 3850411  | 1   | Screw, Throttle lever lower       |       |
| 103 | 3853558  | 2   | Screw, Reservoir to bracket       |       |
| 104 | 3852160  | 3   | Stud, TBI to adapter              |       |
| 105 | 3850274  | 1   | Stud, Flame arrestor              |       |
| 106 | 3850354  | 1   | Throttle body                     |       |
| 107 | 3850271  | 1   | Bracket, Reservoir                |       |
| 108 | 3850753  | 1   | Screw, Reservoir bracket to block |       |
| 109 | 3850275  | 1   | Bracket, Fuel line                |       |
| 110 | 3852435  | 1   | Hose, Crankcase vent              |       |
| 111 | 3852668  | 1   | Hose, Crankcase vent              |       |
| 112 | 3850556  | 1   | Cover                             |       |
| 114 | 3850689  | 1   | Hose, Reservoir to pulse limiter  |       |
| 115 | 3850657  | 2   | Nut, Reservoir to bracket         |       |
| 116 | 3850280  | 1   | Flame trap                        |       |
| 117 | 3852225  | 1   | Impulse limiter, Pulse            |       |