



# OIL PAN & LUBRICATION

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852822	1	Gasket, Oil pan	5.0 Litre
	3852823	1	Gasket, Oil pan	5.8 Litre
2	3853070	1	Retainer, Oil pump shaft	5.0 Litre
	3853005	1	Retainer, Oil pump shaft	5.8 Litre
3	3853006		Screw, Oil pan	
4	3853032		Screw, Pickup tube	
6	3853033		Screw, Oil pan	
7	3853797	1	Oil pan	5.0 Litre
	3853798	1	Oil pan	5.8 Litre
	3853034	1	Plug, Oil indicator hole	5.8 Litre
8	3853069	1	Oil pump screen, Oil pump	5.0 Litre
	3853104		Oil pump screen, Oil pump	5.8 Litre
9	3853068		Shaft, Oil pump	5.0 Litre
	3853105	1	Shaft, Oil pump	5.8 Litre
10	3853071	1	Reinforcement, Oil pan, stbd	5.0 Litre
	3853106		Reinforcement, Oil pan, , stbd	5.8 Litre
11	3853072	1	Reinforcement, Oil pan, port	5.0 Litre
	3853107	1	Reinforcement, Oil pan, port	5.8 Litre
12	3853909		Oil pump	5.0 Litre
	3853908		Oil pump	5.8 Litre
13	3854145	1	Tube, Oil drain	5.0 Litre
	3854170	1	Tube, Oil drain	5.8 Litre
14	3850474	1	Oil dipstick	5.0 Litre
	3850473	1	Oil dipstick	5.8 Litre
15	3853469	1	Sealing washer, Fitting	5.0 Litre
	3853725	1	Sealing washer, Fitting	5.8 Litre
16	3852694	1	Hollow screw, Oil drain	5.0 Litre
	3852609	1	Hollow screw, Oil drain	5.8 Litre
17	3855112		Fitting, Oil drain	
18	3853674		O-ring, Oil drain	
19	3852007		Washer, Retainer	
20	3853267		Gasket, Oil screen	
21	3852788		Screw, Oil pump to block	
22	3852033		O-ring, Oil drain tube	