

Upd: 22 NOV 2005

1	REF	PART NO.	QTY	DESCRIPTION	NOTES
2 3853105					NOTES
3 3854419 1 Hose, Adapter to filter 4 3854418 1 Hose, Adapter to cooler 6 3853006 4 Screw, Oil pan 7 385819 6 Oring, Oil hose 8 3853106 1 Reinforcement, Oil pan, stbd 9 3852620 1 Cable clamp, Oil lose 10 3852079 1 Nut, Oil cooler 12 3852126 1 Clamp, Oil cooler 13 3853236 1 Screw, Oil cooler 14 3854413 1 Bracket, Oil filter 15 3854526 1 Oil filter fousing, Oil filter 16 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 18 3852099 1 Oring, Retainer to adapter 20 385779 1 Oil filter 21 3852609 1 Hollow screw, Oil drain 22 3853007 1 Washer, Retainer					
4 3854418 1 Hose, Adapter to cooler 5 3854417 1 Hose, Filter to cooler 6 3853006 4 Screw, Oil pan 7 3850819 6 Oring, Oil hose 8 3853106 1 Reinforcement, Oil pan, stbd 9 3852620 1 Cable clamp, Oil lines 10 3852278 1 Nut, Oil cooler 11 3852218 1 Clamp, Oil cooler 12 3852326 1 Spacer, Oil cooler 14 3853332 1 Spacer, Oil filter 15 3854332 1 Bracket, Oil filter 16 3854414 1 Adapter, Engine oil 17 3854416 1 Oring, Retainer to adapter 19 385415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852099 1 Hollow screw, Oil drain 22 3853075 1 Sealing washer, Fitting <t< td=""><td></td><td></td><td></td><td></td><td></td></t<>					
5 3854417 1 Hose, Filter to cooler 6 3853006 4 Screw, Oil pan 7 3850819 6 O-ring, Oil hose 8 3853106 1 Reinforcement, Oil pan, stbd 9 3852620 1 Cable clamp, Oil lines 10 3852079 1 Nut, Oil cooler 11 385218 1 Clamp, Oil cooler 12 3852126 1 Screw, Oil cooler 13 3853236 1 Spacer, Oil cooler 14 3854413 1 Bracket, Oil filter 15 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852009 1 Hollow screw, Oil drain 22 3853007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting	-				
6 3853006 4 Screw, Oil pan 7 3850819 6 O-ring, Oil hose 8 3852106 1 Reinforcement, Oil pan, stbd 9 3852079 1 Nut, Oil cooler 10 385218 1 Clamp, Oil cooler 12 3852126 1 Screw, Oil cooler 13 3853236 1 Spacer, Oil cooler 14 3854413 1 Bracket, Oil filter 15 3854392 1 Oil filter housing, Oil filter 16 3854416 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 18 3852089 1 O-ring, Retainer, Adapter 20 835779 1 Oil filter 21 3852009 1 Hollow screw, Oil drain 22 3853072 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853969 1 Oil cooler				Hose, Filter to cooler	
8 3853199 6 O-ring, Oil hose 8 3853106 1 Reinforcement, Oil pan, stbd 9 3852620 1 Cable clamp, Oil lines 10 3852079 1 Nut, Oil cooler 11 3852218 1 Clamp, Oil cooler 12 3852126 1 Screw, Oil cooler 14 3854413 1 Bracket, Oil filter 15 3854413 1 Bracket, Oil filter 16 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 18 3852089 1 Oil filter 20 835779 1 Oil filter 21 3852007 1 Washer, Retainer 22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853969 1 Oil roal 26	-				
8 3853106 1 Reinforcement, Oil pan, stbd 9 3852620 1 Cable clamp, Oil fines 10 3852079 1 Nut, Oil cooler 11 3852126 1 Screw, Oil cooler 12 3852126 1 Screw, Oil cooler 13 3853236 1 Spacer, Oil cooler 14 3854413 1 Bracket, Oil filter 15 3854413 1 Dracket, Oil filter 16 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852009 1 Hollow screw, Oil drain 22 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853667 1 O-ring, Oil drain 26 3853969 1 Oil cooler					
9 3852620					
10					
11					
12					
13					
14 3854413 1 Bracket, Oil filter 15 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, 18 3852089 1 O-ring, Retainer to adapter 19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852009 1 Hollow screw, Oil drain 22 3852725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853725 1 Sealing washer, Fitting 24 3853969 1 Oil cooler 27 3853666 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3853266 2 Screw, Adapter to bracket 32 3853266 2 Screw, Adapter to bracket			1		
15			1		
16 3854414 1 Adapter, Engine oil 17 3854416 1 O-ring, Retainer to adapter 18 3852089 1 O-ring, Retainer to adapter 20 835779 1 Oil filter 21 3852609 1 Hollow screw, Oil drain 22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853664 1 Fitting, Oil drain 26 3853969 1 Oil cooler 27 3852662 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 385120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain			1		
17 3854416 1 O-ring, Retainer to adapter 18 3852089 1 O-ring, Retainer to adapter 19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852007 1 Hollow screw, Oil drain 22 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853606 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCN 34 3850303 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE onl <td></td> <td></td> <td>1</td> <td></td> <td></td>			1		
19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852609 1 Hollow screw, Oil drain 22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCN 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1	17		1		
19 3854415 1 Retainer, Adapter 20 835779 1 Oil filter 21 3852609 1 Hollow screw, Oil drain 22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 385120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCN 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1	18	3852089	1		
20 835779 1 Oil flitter 21 3852609 1 Hollow screw, Oil drain 22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853674 1 O-ring, Oil drain 26 3853969 1 Oil cooler 27 3852666 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3850473 1 Oil dipstick INCC, PNCB, PNCBCE, PNCS, PNCSCE only 36 3850394 1 Oil pan 38		3854415	1	Retainer, Adapter	
22 3852007 1 Washer, Retainer 23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853664 1 Oring, Oil drain 26 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCA 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3853908 1 Oil pam 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 40 3853032 2 Screw, Pickup tube			1		
23 3853725 1 Sealing washer, Fitting 24 3853664 1 Fitting, Oil drain 25 3853674 1 O-ring, Oil drain 26 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCN 34 3850473 1 Oil dipstick INCC, PNCB, PNCBCE, PNCS, PNCSCE only 35 3852823 1 Gasket, Oil pan 36 3853908 1 Oil pan 37 3853908 1 Oil pump 38 3853471 2 Screw, Pickup tube 39 3853032 2					
24 3853664 1 Fitting, Oil drain 25 3853674 1 O-ring, Oil drain 26 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853032 2 Screw, Pump to block 40 3853032 2 Screw, Pump to block 41 3853033 18 Screw, Oil pan					
25 3853674 1 O-ring, Oil drain 26 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3850473 1 Oil dipstick INCC, PNCB, PNCBCE, PNCS, PNCSCE onload 34 3850473 1 Oil pan 36 3853908 1 Oil pan 36 3853908 1 Oil pump 38 3853471 2 Screw, Pickup tube 39 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 40 3853033 18 Screw, Oil			1		
26 3853969 1 Oil cooler 27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3850473 1 Oil dipstick INCC, PNCB, PNCBCE, PNCS, PNCSCE only 35 3852823 1 Gasket, Oil pan INCS, PNCB, PNCBCE, PNCS, PNCSCE only 36 3850394 1 Oil pump INCS, PNCB, PNCBCE, PNCS, PNCSCE only 39 3853471 2 Gcrew, Pickup tube INCS, PNCB, PNCBCE, PNCS, PNCSCE, PNCS					
27 3853266 2 Screw, Bracket to elbow 28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3853994 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
28 3850907 1 Hose, Oil cooler to oil cooler 29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3853994 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853033 18 Screw, Oil pan					
29 3852602 3 Clamp, Hose 30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 40 3853032 2 Screw, Pickup tube 40 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
30 3853005 1 Retainer, Oil pump shaft 31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 40 3853032 2 Screw, Pickup tube 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
31 3855120 1 Hose, Cooler to thermostat 32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 34 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 40 3853032 2 Screw, Pickup tube 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan				Clamp, Hose	
32 3853266 2 Screw, Adapter to bracket 33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 40 3853032 2 Screw, Pickup tube 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
33 3854170 1 Tube, Oil drain INCS, PNCA, PNCACE, PNCD, PNCM, PNCM 3855503 1 Tube, Oil drain INCC, PNCB, PNCBCE, PNCS, PNCSCE only 34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan				Hose, Cooler to thermostat	
3855503				Screw, Adapter to bracket	INIOS BUOM BUOM OF BUOM BUOM BUOMOF
34 3850473 1 Oil dipstick 35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan	33				INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE ONLY
35 3852823 1 Gasket, Oil pan 36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan	0.4				INCC, PNCB, PNCBCE, PNCS, PNCSCE only
36 3850394 1 Oil pan 37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
37 3853908 1 Oil pump 38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
38 3853267 1 Gasket, Pickup tube 39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
39 3853471 2 Screw, Pickup tube 40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
40 3853032 2 Screw, Pump to block 41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
41 3853104 1 Oil pump screen, Oil pump 42 3853033 18 Screw, Oil pan					
42 3853033 18 Screw, Oil pan					
43 3853107 1 Reinforcement, Oil pan, port				Screw Oil nan	
		3853107		Reinforcement Oil nan nort	
	10	0000107	•	remore empari, pore	