


# ENGINE WIRE HARNESS & BRACKET, Fi



# ENGINE WIRE HARNESS & BRACKET, Fi

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3856495	1	Cable harness, Engine	
2	3852527	2	· Cable terminal, 0.375	
3	3852235	X	· Cable terminal, #10	
4	3852229	10	· Cable terminal, Pin	
5	3853675	X	· Cable terminal	
6	3853705	X	· Connector	
7	3853534	2	· Cable terminal	
8	3853676	9	· Cable terminal	
9	3853565	X	· Connector, 2 pin	
10	3853677	X	· Retainer	
11	3853678	X	· Connector	
12	3852254	4	· Cable terminal, Receptacle	
13	3854192	X	· Connector	
14	3852107	2	· Cable terminal, 0.25	
15	3852130	1	· Rubber cap	
16	3852230	3	· Plug, Connector seal	
17	3852036	1	· Cable terminal, Alternator ground	
18	3853679	6	· Cable terminal	
19	3852260	1	· Connector, Receptacle	
20	3853681	3	· Cover	
21	3853682	X	· Cable terminal	
22	3853683	X	· Cable terminal	
23	3853533	12	· Cable terminal, Socket	
24	3853684	X	· Cable terminal	
25	3853685	X	· Retainer	
26	3852244	2	· Cable terminal, Socket	
27	3852181	2	· Cap	
28	3852233	5	· Cable terminal, #10	
29	3853689	X	· Retainer	
30	3853690	X	· Connector	
31	3853479	1	Cable terminal	
32	3853478	1	· Seal	
33	3853480	1	Terminal casing	
34	3852084	X	· Cable terminal, Side rcpt	
35	3853320	1	· Cover	
36	3853691	X	· Cable terminal	
37	3853692	X	· Cable terminal	
38	3853693	X	· Retainer	
39	3853694	X	· Connector	
	3854164	1	Fuse, 50A, tilt & trim	
40	3853695	X	· Cable terminal	
41	3853696	X	· Retainer	
42	3853697	X	· Connector	
43	3853698	12	· Cable terminal	
44	3853699	X	· Retainer	
45	3853995	1	· Connector	
46	3853700	X	· Retainer	
47	3853701	X	· Connector	
48	3853702	X	· Retainer	
49	3854115	1	· Connector	
50	3852248	X	· Cable sleeve, Socket, blue	
51	3853703	X	· Connector	
52	3854114	X	· Housing	
53	3853704	X	· Connector	
54	3852242	2	· Pin connector, 4 pin	
55	3853706	1	· Cable sleeve	
56	3853707	1	· Cable terminal	
57	3852246	X	· Cable terminal, Receptacle, 0.250	
58	3852247	1	· Cable terminal, Receptacle, 0.250	
59	3852210	1	· Bracket	
60	3852259	1	· Relay, Fuel pump	
61	3850985	1	Fuse, 50A	
62	3852499	1	· Retainer	
63	3852158	1	Lock strap, ECA relay to elec comp brkt	

7797220 - - 0-0011

GR950303

Upd: 22 NOV 2005

NC 5.0 FL, 5.0 Fi

**VOLVO**  
**PENTA**

# ENGINE WIRE HARNESS & BRACKET, Fi

REF	PART NO.	QTY	DESCRIPTION	NOTES
64	3852258	3	· Diode	
65	3853688	X	· Connector	
66	3853687	1	Cover, Connector housing	
67	3854162	1	Breaker, 12.5A, electronic engine control	
	3854164	1	Fuse, 50A, engine	
	3854186	1	Fuse, 60A, engine	
68	3854205	1	Cable, Solenoid to solenoid	
69	3853752	1	Lock strap, Engine cable boot to ECA cover	
70	3853786	1	Clamp, Instrument cable connector	
71	3853611	1	Cover, Self test output connector	
72	3854189	1	Cover, ECA module	
73	3852195	1	Grommet, Electrical component bracket	
74	3853643	1	Bridge connector, Timing test lead	
75	3854185	1	Cable, Solenoid to 50A circuit breaker	
	3854185	1	Cable, Solenoid to 60A circuit breaker	
76	3852037	X	Cable terminal, Ring, 0.312	
77	3852245	1	Cable terminal	
78	3854889	1	Control unit, Electronic Engine Control 5.0 L	
79	3852042	2	Nut, Leads to start assist solenoid	
80	3852064	2	Nut, Assist solenoid	
81	3854138	1	Relay, Starter motor	
82	3852825	1	Retainer, Engine cable	
83	3852194	2	Screw, Start assist solenoid to bracket	
84	3852208	3	Screw, Retainer	Engine cable end to bracket
85	3852208	4	Screw, ECA module cover to elec comp brkti	
86	3852212	1	Screw, ECA relay to elec comp brkt	
87	3852454	1	Screw, Elec comp brkt to lift bracket	
88	3853620	2	Screw, Circuit breaker to bracket	Tilt & trim
89	3853839	1	Solenoid, Starter	
90	3853617	3	Sleeve, Bushing, grommet, elec comp brkt	
91	3852136	3	Washer, Screw, elec comp brkt	
92	3852064	6	Nut, Circuit breaker terminals	
93	3852055	2	Washer, Leads to start assist solenoid	
94	3852001	6	Lock washer, Circuit breaker terminals, engine & ECA	
95	3852001	4	Lock washer, Lead to start assist solenoid	
96	3852237	1	Retainer, Amphenol. trim sender, 2 terminal	
97	3852238	1	Retainer, Engine cable to knock module assy	
	3852238	1	Retainer, Shift assist & neutral drive switches	
98	3854216	1	Control unit	
99	3852241	1	· Connector, 4 socket	
100	3852257	4	· Cable terminal, Socket	
101	3852487	1	· Protective cap, Battery cable	
102	3853734	1	· Clip, Self test output connector cover	
103	3852411	1	Connector, Shift assist & neutral drive switches	
104	3852230	2	· Plug, Connector seal	
105	3852241	1	· Connector, 4 socket	
106	3852257	1	· Cable terminal, Socket	
107	3853569	1	Bracket, Electrical components	