



EXHAUST & COOLING, Fi / FSi

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3853245	1	Adapter, Thermostat hsg	
2	3853651	8	Screw, High rise elbow to exhaust manifold	
3	3852111	1	Gasket, Thermostat hsg to engine	
4	3852071	1	O-ring, Thermostat	
5	3852216	1	Thermostat, Engine	
6	3853471	2	Screw, Adapter to intake manifold, therm hsg	
7	3850360	1	Thermostat housing, Thermostat hsg	
8	3852196	1	Clamp, Hose to reservoir, antisiphon valve	
9	3853155	6	Screw, Exhaust manifold	
10	3853391	1	Screw, Lift bracket & thermostat hsg	To intake manifold
11	3853401	1	Screw, Thermostat hsg to adapter, short	
12	3852098	2	Clamp, Therm hsg to water pump	
13	3852300	1	Hose, Thermostat hsg to water pump	
14	3853404	12	Lock nut, Exhaust manifold to engine	
15	3853633	1	Hose, Thermostat hsg to exhaust manifold	Port
16	3853420	1	Hose, Thermostat hsg to exhaust manifold	Stbd
17	3853780	2	Clamp, To thermostat hsg	
18	3852602	2	Clamp, Cap to exhaust manifold	
19	3852602	1	Clamp, To thermostat hsg inlet	
20	3853581	1	Hose, Oil cooler to thermostat hsg	
21	3852456	1	Gasket, Therm adapter to intake manifold	
22	3852476	2	Cap, Exhaust manifold	
23	3852602	2	Clamp, To exhaust manifold	
24	3852604	8	Clamp, Hose, exhaust pipe upper to lower	
25	3852604	8	Clamp, Hose, exhaust pipe upper to lower	
26	3853434	10	Stud, Exhaust manifold to cylinder head	
27	3855472	4	Screw, Pipe to gimbal	
28	3855281	1	Exhaust pipe, SX, DP-S	
	3851000	1	Exhaust pipe, 290 DP	
29	3850496	2	· Gasket, Elbow to exhaust manifold	
30	3850422	1	· Clamp, Water pump inlet	
31	3850361	1	· Hose, Transom to water pump	290 DP
	3852331	1	· Hose, Gimbal hsg to water pump	SX, DP-S
32	3852753	2	· Pin, Exhaust seal assy to exhaust pipe	
33	3855517	4	· Bushing, Exhaust seal assy to exhaust pipe	
34	3852649	1	Bracket, Center lift	
35	3855269	1	Exhaust pipe, Starboard	
	3855271	1	Exhaust pipe, Port	
	3850740	2	· Plug, Exhaust elbow	
36	3853641	2	Hose, Exhaust pipe	
37	3853390	4	Screw, Water pump pulley to hub	
38	3853615	2	Exhaust pipe, Exhaust pipe assy to exhaust elbow	
	3854500	2	Exhaust riser, Upper high rise elbow to Y-pipe	290 DP
39	3854187	1	Pulley, Water pump	
40	3853608	2	Exhaust hose, Exhaust elbow to exhaust pipe, upper	
41	3852741	2	Hose, Upper exhaust pipe to exhaust pipe	
42	3853796	1	Coolant pump	INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE only
	3851995	1	Sea water pump	INCC, PNCCB, PNCCBCE, PNCS, PNCSCE only
43	3850596	1	· Gasket, Water pump plate	
44	3852824	1	Gasket, Water pump	
45	3852347	2	Exhaust pipe, Exhaust	Port & stbd
46	3853598	1	Riser, Hose to reservoir	
47	3853787	1	Temperature sensor, Water temperature	
	3855107	1	Water temp, dual station	
48	3855640	1	Bracket, Water pump	INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE only
	3855702	1	Bracket, Water pump	INCC, PNCCB, PNCCBCE, PNCS, PNCSCE only
49	973535	1	V-belt, Water pump	
50	3850633	1	Hose, Antisiphon valve to therm hsg	
51	3852088	1	Clamp, Hose, therm hsg to reservoir	
52	3850654	1	Hose, Reservoir to antisiphon valve	
53	3850666	1	Nipple, Hoses, thermostat hsg to reservoir	

EXHAUST & COOLING, Fi / FSi

REF	PART NO.	QTY	DESCRIPTION	NOTES
54	3854925	1	Clamp, Hose, antisiphon valve from reservoir	
55	3853326	2	Screw, Water pump bracket to engine	
56	3853397	2	Screw, Water pump to bracket	INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE only
	3853155	2	Screw, Water pump to bracket	INCC, PNCB, PNCBCE, PNCS, PNCSCE only
57	3853713	1	V-belt, Alternator pulley	
58	3852332	1	Hose, Water pump to reservoir	
59	3852602	1	Clamp, Gimbal housing	
60	3851623	1	Sea water pump	INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE only
	3851995	1	Sea water pump	INCC, PNCB, PNCBCE, PNCS, PNCSCE only
61	3853742	2	Gasket, Manifold to engine	
62	3852054	2	Washer, Screw, water pump to bracket	INCS, PNCA, PNCACE, PNCD, PNCM, PNCMCE only
	3852162	2	Washer, Screw, water pump to bracket	INCC, PNCB, PNCBCE, PNCS, PNCSCE only