



INBOARD MOUNTING COMPONENTS, HS1

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3851723	1	Flywheel housing	
	3853003	1	Cover	Not shown
	3852421	5	Screw, Flywheel cover to hsg	Not shown
2	955860	4	Nut, Engine mount	
3	955555	4	Screw, Flywheel housing to engine	
4	941909	6	Spring washer, Screw, flywheel housing	
5	3850520	1	Vibration damper, Flywheel	
6	3854495	6	Stud, Dampener to flywheel	
7	3854496	6	Washer, Dampener to flywheel	
8	3854497	6	Lock nut, Dampener to flywheel	
9	3851758	2	Bracket, Rear mount	
10	965187	8	Screw, Rear engine mount to flywheel hsg	
11	841247	4	Pin, Engine mount	
12	950355	4	Nut	
13	955860	2	Nut, Rear mount	
14	3851757	2	Bracket, Front mount to engine block	
15	955551	4	Screw, Mount assy, pin clamp	
16	950355	4	Nut, Mount assy, pin clamp	
17	941909	4	Spring washer, Mount assy, spring clamp	
18	3853626	4	Screw, Front mount bracket to engine	
19	857251	1	Rubber cushion	