



EEM IGNITION, GL

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3852099	3	Nut, Module to bracketi	
2	3853377	1	Bracket, Ignition module	
3	3853549	1	Coil to distributor	
4	3853829	2	Distributor to #1 & 2	
	3853830	2	Distributor to #7 & 8	
	3853831	2	Distributor to #3 & 4	
	3853832	2	Distributor to #5 & 6	
5	3854230	1	Icm, Ignition	
6	3853298	6	· Screw, Ignition module	
7	3853299	1	· Gasket, Connector	
8	3853297	1	· Gasket, Ignition module	
9		1	· MODULE, Ignition	
10	3852217	1	· Ignition coil, Ignition module	
11	3853552	1	· Screw, Coil bracket	
12	3853553	1	· Cover, Ignition module	
13	3853554	1	· Grommet, Ignition module	
14	3853555	1	· Bracket, Ignition module	
15	3852001	2	· Lock washer, Ignition coil	
16	3852064	2	· Nut, Ignition coil	
17	3852492	1	Retainer, Ignition leads	
18	3854128	1	Distributor	
19	3853888	1	· Gear set, Distributor	
20	3853815	1	· Cover, Distributor	
21	3854134	1	Rotor	
22	3853795	1	· Bearing	
23	3853812	1	· Bracket	
24	3852099	4	Nut	
25	3853990	1	Icm, Crankshaft	
26	3853259	1	· Spring, Sensor locator	
27	3853260	1	· Sensor, Ignition sensor	
28	3852828	1	Cap, Sensor	
29	3853300	2	Stud, Sensor cover	
30	3852952	1	Ring, Ignition timing	
31	3852183	2	Washer, Sensor to flywheel hsg	
32	3853300	2	Stud, Sensor to flywheel housing	
33	3852827	3	Bracket, Spark plug leads	
34	3853389	1	Screw, Retainer, port	PNCA only
	3853154	1	Screw, Retainer, port	PNCM only
	3853557	1	Screw, Retainer, stbd	PNCA only
	3853389	1	Screw, Retainer, stbd	PNCM only
35	3852491	2	Retainer, 4 wire	
36	3852619	3	Retainer, Leads	
37	3853956	1	Knock sensor	
38	3853428	1	Screw, Bracket to high rise	
39	3852162	1	Washer, Sensor spacer	
40	3852162	1	Washer, Spacer, stbd	PNCA only
	3852116	1	Washer, Spacer, stbd	PNCM only
41	3854388	1	Adapter, Knock sensor	PNCM only