

| DESCRIPTION                             | SEE SEC. | NOTES                  |
|-----------------------------------------|----------|------------------------|
| Serpentine Belt and Alternator          | 37860    | V8-300-E-B, V8-320-E-B |
| Starter                                 | 8730     | V8-300-E-B, V8-320-E-B |
| Key Switch and Interface                | 36256    | V8-300-E-B, V8-320-E-B |
| EVC Cables                              | 37395    | V8-300-E-B, V8-320-E-B |
| Engine Harness                          | 37674    | V8-300-E-B, V8-320-E-B |
| Fuse and Relay Box                      | 37675    | V8-300-E-B, V8-320-E-B |
| Tachometers and Speedometers, EVC       | 36261    | V8-300-E-B, V8-320-E-B |
| Gauges, EVC                             | 22179    | V8-300-E-B, V8-320-E-B |
| Gauges, 4-in-1, EVC                     | 22182    | V8-300-E-B, V8-320-E-B |
| Information Display 2.5", EVC-E, EVC-D  | 37248    | V8-300-E-B, V8-320-E-B |
| Generic Button Panel 2.5", EVC-E, EVC-D | 37253    | V8-300-E-B, V8-320-E-B |
| 4" Color Display, EVC-E                 | 37259    | V8-300-E-B, V8-320-E-B |
| e-Key, EVC-E                            | 37277    | V8-300-E-B, V8-320-E-B |
| Auto Pilot, EVC-E                       | 37328    | V8-300-E-B, V8-320-E-B |
| 7" Color Display, EVC-E2                | 37732    | V8-300-E-B, V8-320-E-B |
| Multi-sensors and Senders, EVC          | 22185    | V8-300-E-B, V8-320-E-B |
| OceanX™ Drive Sensors                   | 35818    | V8-300-E-B, V8-320-E-B |
|                                         |          |                        |