


# ENGINE WIRE HARNESS, Gi / GSi



# ENGINE WIRE HARNESS, Gi / GSi

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3858281	1	Wiring harness	
2	3852527	1	Cable terminal, Alternator ground	Black
3	3852527	1	Cable terminal, Trim sender fuel pump ground	Black
4	3852229	2	Cable terminal	
5	3853565	2	Connector, 2 pin	
6	3852229	2	Cable terminal, Trim sender	
7	3854244	1	Cable, Ignition coil	
8	3853320	1	Cover, Oil pressure switch	
9	3852084	1	Cable terminal, Oil pressure switch	Tan/black
10	3852245	1	Cable terminal, Alternator ground	Black
11	3852235	1	Cable terminal, Alternator excite	Purple
12	3852130	1	Rubber cap, Alternator output	
13	3852038	1	Cable terminal, Alternator output	Orange
14	3852233	1	Cable terminal, Alternator output	
15	3857189	1	Seal, Knock sensor	
16	3853480	1	Terminal casing, Knock sensor	
17	3852235	1	Cable terminal, Starter solenoid-starter terminal	Yellow/red
18	3852527	1	Cable terminal, Starter solenoid	
19	3852245	1	Cable terminal	
20	3852245	1	Cable terminal	
21	3852235	1	Cable terminal	
22	3854164	2	Fuse, 50 amp	
23	3852245	1	Cable terminal	
24	3852235	1	Cable terminal	
25	3854163	1	Breaker, 20 amp	
26	3852245	1	Cable terminal	
27	3852227	1	Cable terminal, Electrical bracket ground	Black
28	3854192	1	Connector, Starter relay	
29	3854192	4	Connector, Starter relay	
30	3852158	1	Lock strap, Shift interrupt to cable trunk	
31	3853565	1	Connector, 2 pin shift interrupt	
32	3852229	2	Cable terminal, Shift interrupt	
33	3853681	1	Cover, Low pressure fuel pump	
34	3853679	2	Cable terminal, Low pressure fuel pump	
35	3852210	1	Bracket, Fuel pump ignition relay	
36	3852246	4	Cable terminal, Fuel pump ignition relay	
37	3852247	4	Cable terminal, Fuel pump ignition relay	
38	3850025	1		
39	3852235	2	Cable terminal, Fuel pump circuit breaker	
40	3852233	1	Cable terminal, Fuel pump circuit breaker	
41	3854163	1	Breaker, 20 amp	
42	3852233	1	Cable terminal, Water temp transmitter	
43	3852233	1	Cable terminal, Oil pressure transmitter	
44	3853681	1	Cover, High pressure fuel pump	
45	3855021	1	Housing, High pressure fuel pump	
46	3853679	2	Cable terminal, High pressure fuel pump	
47	3855245	1	Connector	
48	3858863	1	Ecu	Gi
	3858888	1	Ecu	GSi
49	3850357	1	Knock sensor	
50	3850397	1	Ect sensor	
51	3850396	1	Sender	
52	3857815	1	Bracket, ECM and MAP sensor	
53	3852115	2	Screw, MAP sensor bracket	
54	3852053	3	Screw, ECM to bracket	
55	3857179	4	Hose, MAP sensor	
56	3853398	1	Screw, ECU bracket to riser	