



6018

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	846107	1	Clutch	11 1/2"- AP111 SINGLE PTO SER.62596.
2	806009	1	• Drive ring	
3	805499	1	• Bearing	
4	827624	1	• Nut	
5	827625	1	• Lock washer	
6	827628	1	• Pressure plate	
7	846392	2	• Disc	
8	804831	1	• Intermediate plate	
9	825504	4	• Locating pin	
10	804857	8	• Washer	
11	825503	4	• Lock pin	
12	804854	4	• Lever	
13	846397	1	• Throw-out bearing	
14	827354	8	• • Clevis pin	
15	804834	8		
16	907861	8	• • Cotter pin	
17	804837	1	• • Bearing sleeve	
18		2	• • • SCREW	
19	804840	2	• • • Adjusting washer	
20		2	• • • NUT	
21		1	• • • COLLAR	
22	804814	1	• Adjusting ring	
23	846395	1	• Lock pin	
24	846396	1	• Spring	
25	846393	1	• Disc	
26	806038	1	• Hose	
27		1	• • NIPPLE	
28		1	• • NIPPLE	
29	805521	1	• Screw	
30	808733	1	• Lock washer	
31	805498	1	• Lock washer	
32	827623	1	• Protecting ring	
33	955953	1	• Lock washer	
34	805560	1	• Nut	
35	914167	1	• Lubricating nipple	
36	805745	1	• Companion flange	
37	914167	1	• Lubricating nipple	
38	805826	1	• Housing	
39	805739	1	• Release fork	
40	846391	1	• Roller bearing	
41	805397	1	• Nipple	
42	805582	1	• Key	
43	846390	1	• Shaft	
44	805587	1	• Key	
45	846391	1	• Roller bearing	
46	805808	1	• Lever	
47	955563	1	• Screw	
48	805557	2		
49	805430	1	• Shaft	
50	806007	1	• Hatch	
51	805558	2	• Screw	
52	805431	1	• Gasket	
53	805431	1	• Gasket	
54	806008	1	• Plate	
55	805558	2	• Screw	
56	940162	2	• Screw	
57	955950	2	• Lock washer	
58	827627	2	• Lubricator	
59	940280	6	• Spring washer	
60	955564	6	• Screw	