



REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	820585	1	Air filter		EARLY TYPE
2	822137	3	Filter insert		EARLY TYPE
3	823701	1	Air filter		LATE TYPE
4	842037	1	Vacuum gauge		
5	191095	1	Nipple		
6	821028	1	Tensioning band		
	821028	2	Tensioning band		FOR ENGINE WITH TUBE HEAT EXHANGER.
7	31404	1	Pin, THREADED		
	31404	2	Pin, THREADED		FOR ENGINE WITH TUBE HEAT EXHANGER.
8	31405	1	Pin		
	31405	2	Pin		FOR ENGINE WITH TUBE HEAT EXHANGER.
9	31406	1	Screw		
	31406	2	Screw		FOR ENGINE WITH TUBE HEAT EXHANGER.
10	824276	1	Bracket		
	824276	2	Bracket		FOR ENGINE WITH TUBE HEAT EXHANGER.
11	820508	1	Spacer sleeve		L = 28 MM
	820507	1	Spacer sleeve		L = 40 MM
	820506	2	Spacer sleeve		L = 9 MM
12	821267	1	Screw		L = 85 MM. WHEN EMERGENCY STOP IS INSTALLED.
	821268	1	Screw		L = 73 MM. WHEN EMERGENCY STOP IS INSTALLED.
	821269	2	Screw		L = 41 MM. WHEN EMERGENCY STOP IS INSTALLED.
13	955531	2	Screw		L = 89 MM
	955531	4	Screw		FOR ENGINE WITH TUBE HEAT EXHANGER.
	940135	4	Screw		L = 22 MM. WHEN EMERGENCY STOP IS INSTALLED.
14	955894	2	Washer		
	955894	4	Washer		FOR ENGINE WITH TUBE HEAT EXHANGER.. WHEN EMERGENCY STOP IS INSTALLED.
15	820760	1	Cover		
16		1	• CLAMP		
17	955535	1	• Screw		
18	955827	1	• Nut		
19	942336	1	• Spring washer		
20	822116	1	Protecting grating		WHEN DOUBLE SHEATED FUEL PIPES ARE INSTALLED.
21	955113	3	Screw		WHEN DOUBLE SHEATED FUEL PIPES ARE INSTALLED.
22	821181	1	Hose		FOR ENGINE WITH TUBE HEAT EXHANGER.. WHEN DOUBLE SHEATED FUEL PIPES ARE NOT INSTALLED.
23	942713	X	Rubber hose		L = 80 MM.. ENGINE WITHOUT EMERGENCY STOP.
24	340921	1	Hose		D = 89 MM-102 MM. REPLACED BY 1EA 820637, 1EA 950564.
25	943484	2	Hose clamp		(951801)
26	820996	1	Flange		FOR 807704.
29	402185	1	Gasket	IK	
31	956570	4	Screw		
33	955894	4	Washer		
38	417144	1		02B-1100	FOR ENGINE WITH TUBE HEAT EXHANGER.
39	954524	1	Lever		FOR ENGINE WITH TUBE HEAT EXHANGER.
40	959616	1	Screw		FOR ENGINE WITH TUBE HEAT EXHANGER.
41	953466	4	Stud		FOR ENGINE WITH TUBE HEAT EXHANGER.
42	955826	4	Nut		FOR ENGINE WITH TUBE HEAT EXHANGER.
43	955894	4	Washer		FOR ENGINE WITH TUBE HEAT EXHANGER.
44	941907	4	Spring washer		FOR ENGINE WITH TUBE HEAT EXHANGER.