

A - Charging And Starting Circuit
B - Audio Warning/Power Reduction Circuit
C - Instrumentation Senders
a - 90 Amp System Fuse

1 - Harness Connector To Efi System Harness
2 - Positive (+) Power Wire To Efi System Harness
3 - Auxiliary Tachometer Lead

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	84	806656A 6	WIRING HARNESS-ENGINE	1		