DESCRIPTION	SEE SEC.	NOTES
Main Station, Single Installation, EVC-D	36146	D11A-D
Main Station, Twin Installation, EVC-D	36147	D11A-D
Main Station, Triple Installation, EVC-D	36148	D11A-D
Main Station, Quad Installation, EVC-D	36149	D11A-D
Main Station IPS2, Triple Installation, EVC-D	36164	D11A-D MP IPS
Main Station IPS2, Quad Installation, EVC-D	36166	D11A-D MP IPS
Secondary Station, Triple Installation, EVC-D	36151	D11A-D
Secondary Station, Quad Installation, EVC-D	36150	D11A-D
Secondary Station IPS2, Triple Installation, EVC-D	36165	D11A-D MP IPS
Main Station IPS, Twin Electronic Steering, EVC-D	36155	D11A-D
Secondary Station IPS2, Quad Installation, EVC-D	36167	D11A-D MP IPS