



16337

REF	PART NO.	QTY	DESCRIPTION	NOTES
1		1	Reversing gear	RATIO 3.82:1
		1	Reversing gear	RATIO 4.5:1
			Comps. not spec.	
2	955561	8	Screw	
3	940280	8	Spring washer	
4	940134	12	Screw	
5	941909	12	Spring washer	
6	837093	1	Companion flange	SO
7	955773	8	Screw	L=76mm, FOR 955889
	955774	8	Screw	SO L=83mm, FOR 950381
8	941917	8	Spring washer	SO
9	950381	8	Lock nut	SO
10		2	Pin	
11	946834	1	Clamp	For cable, oil pressure sensor.
12	863123	1	Bracket	
13	955524	2	Screw	
14	941907	2	Spring washer	
15	819067	1	Brace	For control cable type 333.
	6853782	1	Clamp	For control cable type 443.
16	819068	1	Washer	
17	956079	2	Screw	
18	963104	2	Nut	
19	853217	1	Cube	
20	940191	1	Washer	
21	907824	1	Cotter pin	
22		X	Control cable	SEE GROUP 27
22A		1	· Nut	
23		X	Control	SEE GROUP 27
24		1	Slip valve	
25	863124	1	Bracket	When trolling valve is installed.